



1422

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	113	888343T	BOTTOM COWL	1	SN# 1B055687 & Below	
1	113	888343T01	BOTTOM COWL	1	SN# 1B055688 THRU 1B226999	
1	113	888343T02	BOTTOM COWL	1	SN# 1B227000 & Up	
2		888349	SEAL	1		
3	10	84059M	BOLT, (M6 x 20)	3		
4	12	804339	WASHER	3		
5	24	804147 1	SPRING	3		
6		888366	HOOK SPRING	3		
7	10	887807	BOLT	4		
8		888364 1	LEVER	1		
9	13	888363	WAVE WASHER	1		
10	23	888362	BUSHING	6		
11		888365	PLATE	1		
12	10	888346	BOLT, (30mm)	8		
13		888364	LEVER	2		
14	13	888363	WAVE WASHER	2		
15		888359	PLATE	1	SN# 1B055687 & Below	
15		888359A01	PLATE KIT, Front and Starboard	1	SN# 1B055688 & Up	
16		888356	PLATE	3		
17	10	888346 1	BOLT, (25mm)	3		
18	54	804300	CLAMP	1		
19		888358	BRACKET	1	SN# 1B055687 & Below	
19		888358001	BRACKET	1	SN# 1B055688 & Up	
20		888359 1	PLATE	1	SN# 1B055687 & Below	
20		NSS	NOT SOLD SEPARATE, Plate Kit (1	SN# 1B055688 & Up	
21		888345	RETAINER	1		
22		888344	BRACKET	1	SN# 1B226999 & Below	
22		888344A02	BRACKET/SEAL KIT	1	SN# 1B227000 & Up	
23	54	879650	CLAMP	2		
24	25	888353	GROMMET	1		
25		888349 1	SEAL	1		
26	54	881360	CLAMP	1		
27		888360	LEVER	1		
28		888361	LEVER	1		
29	25	888347 1	GROMMET	1		
30	25	888354	GROMMET	1		
31		888360 1	LEVER	1		
32	10	888350	BOLT	4		
33	25	888351	GROMMET	8		
34	23	888352	BUSHING	4		
35	22	888355	FITTING	1		