



1420

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	50	888333T 1	STARTER MOTOR	1		
1		888337T	COVER	1		
2		804319	PINION	1		
3		804320	PINION STOP SET	1		
4	10	888342	BOLT	2		
-		804321T 1	GEAR KIT	1		
5		804322	CLUTCH	1		
6	12	804330	WASHER KIT	1		
7		804324	BRACKET	1		
8		804326	RING GEAR	1		
9		804327	GASKET	1		
10	31	804325	BEARING	1		
11		804323	PINION SHAFT	1		
12	43	804329	IDLER GEAR	3	SN# 1B226999 & Below	
12	43	804329001	GEAR, Idler	3	SN# 1B227000 & Up	
13		804328	BRACKET	1		
14		888338	LEVER ASSEMBLY	1		
15		888340	DUST COVER	1		
16		888339A 1	STARTER RELAY ASSEMBLY	1		
17		804314T	STATOR	1		
18		804313T	ARMATURE	1		
19		888334A 1	BRUSH HOLDER ASSEMBLY	1		
20		888335	BRUSH SET	1		
21	24	804317	SPRING	4		
22		881370T	BRACKET	1		
23	10	804335	THRU BOLT, (M6 x 120)	2		
24	10	804337	SCREW, (M4 x 16)	2		
25	10	804605	BOLT, (M8 x 45)	3		
26	13	881377	LOCKWASHER	1		
27	11	82382M	NUT	1		