



1414

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		888238T 1	COVER ASSEMBLY	1	SN# 0T962846 & Below	
1		888238T 02	COVER ASSEMBLY	1	SN# 0T962847 & Up	
2		888239	PLATE	1		
3		888239 1	PLATE	1		
4	10	888240	SCREW	2		
5	10	881326	SCREW, (M4 x 16)	7		
6	19	888265	CAP PLUG	1		
7	32	888248	HOSE	2		
8	22	888247	TEE FITTING	1		
9	32	888249	HOSE	1		
10	54	816311T	CABLE TIE, (8.00 Inches)	2		
11		888245	NEEDLE & SEAT	1		
12	25	881318	O-RING	1		
13		881327	PLATE	1		
14	10	804120	SCREW, (M4 x 8)	1		
15		888244	FLOAT	1		
16	17	881321	PIN, Float	1		
17		888246T	FUEL PUMP	1	SN# 1B055687 & Below	
17		888246T 01	FUEL PUMP	1	SN# 1B055688 & Up	
18	35	881323T	FILTER	1		
19		881324	COVER	1		
20	25	881322	DAMPER	1	SN# 0T962846 & Below	
20	25	881322002	DAMPER	1	SN# 0T962847 & Up	
21	27	881325	GASKET	1		
22		888241T 1	BODY ASSY-VAPOR SEPERATOR	1		
23	19	888242	DRAIN PLUG	1		
24	12	888243	WASHER	1		
25	25	888262	GROMMET	4		
26	23	888263	BUSHING	8		
27		888252	BRACKET	1		
28	23	888253	BUSHING	2		
29	10	888254	BOLT	2		
30		888251T	FUEL PUMP	1	SN# 1B230362 & Below	
30		888251T 01	FUEL PUMP	1	SN# 1B230363 & Up	
31		881350T	RELAY	1		
32	23	888256	SPACER	1		
33	13	881525	LOCKWASHER	1		
34	12	888257	WASHER	1		
35	11	888264	NUT	1		
36		888255T	PLATE	1		
37	10	888261	BOLT	2		