



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1623	822442A83	GEAR HOUSING	1	(BASIC-BLACK)	
1	1623	822442A84	GEAR HOUSING	1	(BASIC-GRAY)	
1	1623	822442A79	GEAR HOUSING	1	(BASIC-WHITE)	
61	31	815480	ROLLER BEARING	1		
62	12	815481	THRUST RING	1		
63		828831A 1	BEARING ADAPTOR ASSEMBLY	1		
64	31	814653	ROLLER BEARING	1		
65	12	18448	THRUST WASHER	2		
66	31	15842	THRUST BEARING	2		
67		818291 1	THRUST RACE	2		
68		814605	KEEPER	2		
69	25	31534	O RING	1		9
70		818290A 8	BEARING CARRIER ASSEMBLY	1		
71	31	30956	ROLLER BEARING	1		
72	26	14077	OIL SEAL (INSIDE)	1		9
73	26	76868	OIL SEAL (OUTSIDE)	1		9
74	14	18323	TAB WASHER	1		
75		79448	COVER	1		
76		76214A 5	ANODIC PLATE	1	THESE REPLACEMENT PARTS.	
77	10	806327	SCREW	1	THESE REPLACEMENT PARTS.	
78	12	835467	THRUST HUB	1	THESE REPLACEMENT PARTS.	
79	13	42351 1	LOCKWASHER	1	THESE REPLACEMENT PARTS.	
80	12	31211A 2	WASHER	1	THESE REPLACEMENT PARTS.	
81	14	816629	TAB WASHER	1	THESE REPLACEMENT PARTS.	
82	11	52707A 1	PROPELLER NUT	1	THESE REPLACEMENT PARTS.	
-	26	816575A 4	G/H SEAL KIT	1		