



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		822344T 5	POWER TRIM ASSEMBLY	1		
-	25	827668A 1	O RING KIT	1		
2		827670A 2	SHOCK ROD ASSEMBLY	1		
3		827671A 1	PILOT CHECK ASSEMBLY	1		
4		827672A 1	TILT RELIEF VALVE ASSEMBLY	1		
5		827673A 1	SUCTION SEAT ASSEMBLY	1		
6		827674A 1	PUMP ASSEMBLY	1		
7		NSS	SPRING/DOWN RELIEF BALL	1		
8		NSS	SCREW (10-32 X 1-1/4 IN.)	2		
9		NSS	FILTER	1		
10		NSS	SEAL RING	1		
11		827675A 1	MOTOR ASSEMBLY	1		
12		NSS	SCREW (1/4-28 X 5/8 IN.)	4		
13		88238A15	GROUND STRAP	1		
14		NSS	LOCKWASHER	1		
15		NSS	O RING	1		
16		NSS	COUPLER	1		
17		827676	MEMORY PISTON	1		
18		813442A 2	MANUAL RELEASE VALVE ASS	1		
19	19	811613	RESERVOIR PLUG	1		
-	84	826802T22	TRIM HARNESS/RELAY	1	(S/N-0T178500 & UP)	
-	84	826802A14	TRIM HARNESS/RELAY	1	(S/N-0T178499 & BELOW)	
20	84	826802T20	TRIM HARNESS	1	(S/N-0T178500 & UP)	
20	84	826802A 9	TRIM HARNESS	1	(S/N-0T178499 & BELOW)	
21		828151A 1	RELAY ASSEMBLY	1		
22		828102	BRACKET	2		
23	25	818967	GROMMET	2		
24	23	818968	BUSHING	2		
25		NSS	DECAL-TRIM RELAY	2		
26	10	826844 30	SCREW (M6 X 30)	2		