



2595

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		822344T10	POWER TRIM ASSEMBLY	1		
-	25	827668A 1	O-RING KIT	1		
2		827670A 2	SHOCK ROD ASSEMBLY	1		
3		827671A 1	PILOT CHECK ASSEMBLY	1		
4		827672A 1	TILT RELIEF VALVE ASSEMBLY	1		
5		827673A 1	SUCTION SEAT ASSEMBLY	1		
6		827674A 1	PUMP ASSEMBLY	1		
7		NSS	NOT SOLD SEPARATE, Spring	1		
8		NSS	NOT SOLD SEPARATE, Screw	2		
9		NSS	NOT SOLD SEPARATE, Filter	1		
10		NSS	NOT SOLD SEPARATE, Seal	1		
11		827675A 1	MOTOR ASSEMBLY	1		
12		NSS	NOT SOLD SEPARATE, Screw	4		
13		88238A15	CABLE	1		
14		NSS	NOT SOLD SEPARATE, Lock	1		
15		NSS	NOT SOLD SEPARATE, O Ring	1		
16		NSS	NOT SOLD SEPARATE, Coupl	1		
17		827676	MEMORY PISTON	1		
18		813442A 2	MANUAL RELEASE ASSEMBLY	1		
19	19	811613	PLUG ASSEMBLY	1		
-	84	826802T28	TRIM HARNESS/RELAY ASSEME	1		
20	84	826802T20	TRIM HARNESS	1		
21		882751A 1	RELAY ASSEMBLY	2		
22		828102	BRACKET	2		
23	25	818967	GROMMET	2		
24	23	818968	BUSHING	2		
25		NSS	NOT SOLD SEPARATE, Decal	2		
26	10	826844 30	SCREW, (M6 x 30)	2		