



1237

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	3411	821773T 1	CLAMP BRACKET (Port)	1		
2	3412	821774T 8	CLAMP BRACKET (Starboard)	1		
3	10	818883A 1	THUMB SCREW ASSEMBLY	2	(MANUAL)	
4		NSS	NOT SOLD SEPARATE, Handle	2	(MANUAL)	
5		NSS	NOT SOLD SEPARATE, Rivet	2	(MANUAL)	
6	12	818884	WASHER	2	(MANUAL)	
7	10	76804 2	SCREW, Hex Shoulder	2	(MANUAL)	
8		822401 1	CAP	1		
9	17	25810	PIN	1		
10	23	86637	BEARING	1		
11	17	822400 2	PIN	1		
12		825271 1	ANODE	1		
13	12	29245	WASHER, (.281 x .500 x .060)	2		
14	10	40003 30	SCREW, (M6 x 25)	2		
15	11	826711 17	NUT, (.500-20)	4		
16	12	28421	WASHER, (1.5 x 3.05 x 0.13) Stain	4		
17	10	814259	SCREW, (.500-20 x 4.00)	4		
18	37	830253	DECAL, Tilt Lock	1		
19		828533T 1	TRIM, HYDRAULIC ASSIST	1	(GAS ASSIST TRIM)	
20		88238A11	CABLE ASSEMBLY	1	(GAS ASSIST TRIM)	
21		828924	TILT LEVER	1	(GAS ASSIST TRIM)	
22		19621	TILT KNOB	1	(GAS ASSIST TRIM)	
23		828930	LEVER ARM	1	(GAS ASSIST TRIM)	
24	13	31030	WAVE WASHER,	1	(GAS ASSIST TRIM)	
25	17	25319	PIN, (.125 x 0.75 Inches)	1	(GAS ASSIST TRIM)	
26		828996 1	LINK	1	(GAS ASSIST TRIM)	
27	11	826709106	NUT, (#10-32)	1	GAS ASSIST TRIM	
28	17	822481	ANCHOR PIN, (14MM)	1	(GAS ASSIST & POWER TRIM) S	
28	17	822481001	PIN, (14 mm)	1	(GAS ASSIST & POWER TRIM) S	
29	23	822482	BUSHING	2	(GAS ASSIST & POWER TRIM)	
30	23	822484	BUSHING	2	(GAS ASSIST & POWER TRIM)	
31	12	825190	WASHER	2	(GAS ASSIST & POWER TRIM)	
32	11	826712	NUT	2	(GAS ASSIST & POWER TRIM)	
33	10	40090 40	SCREW, (M10 x 40)	2	(GAS ASSIST & POWER TRIM)	
34	12	40023 19	WASHER	2	(GAS ASSIST & POWER TRIM)	
35	11	40140	NUT, (M10)	2	(GAS ASSIST & POWER TRIM)	
36	17	853923A 1	PIN	1	(HANDLE-NON POWER TRIM)	
37	24	821461	SPRING	1	(HANDLE-NON POWER TRIM)	
38		NSS	NOT SOLD SEPARATE, Decal-We	1		