



2046

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		822649T	EXHAUST VALVE	2		6
2		832990T 1	INTAKE VALVE	2		6
3	12	825044	SEAT-VALVE SPRING	4		6
4	26	822647	SEAL, Valve Stem	4		6,2
5	24	823678	VALVE SPRING-OUTER	4		6
6		822650	RETAINER	4		6
7	28	822651	KEY	8		6
8		825045A 2	ROCKER ARM	4		6
9	10	825046	SCREW	4		6
10	11	826150	NUT	4		6
11		830274	ROCKER SHAFT	1		6
12		NSS	NOT SOLD SEPARATE, Plug	2		6
13		825050	BRACKET	2		6
14	24	825052	SPRING	1		6
15	10	826410 30	SCREW, M8 x 30	3		6
-	27	830270A02	GASKET SET	1		
-		830271T 3	CYLINDER HEAD	1	(ELECTRIC)	
-		830271T 4	CYLINDER HEAD	1	(MANUAL)	