



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		822344A	5 POWER TRIM ASSEMBLY	1		
-	25	827668A	1 O RING KIT	1		
2		827670A	2 SHOCK ROD ASSEMBLY	1		
3		827671A	1 PILOT CHECK ASSEMBLY	1		
4		827672A	1 TILT RELIEF VALVE ASSEMBLY	1		
5		827673A	1 SUCTION SEAT ASSEMBLY	1		
6		827674A	1 PUMP ASSEMBLY	1		
7		NSS	1 SPRING/DOWN RELIEF BALL	1		6
8		NSS	2 SCREW (10-32 X 1-1/4 IN.)	2		6
9		NSS	1 FILTER	1		6
10		NSS	1 SEAL RING	1		6
11		827675A	1 MOTOR ASSEMBLY	1		
12		NSS	4 SCREW (1/4-28 X 5/8 IN.)	4		6
13		88238A15	1 GROUND STRAP	1		
14		NSS	1 LOCKWASHER	1		6
15		NSS	1 O RING	1		6
16		NSS	1 COUPLER	1		6
17		827676	1 MEMORY PISTON	1		
18		813442A	2 MANUAL RELEASE VALVE ASS	1		
19	19	811613	1 RESERVOIR PLUG	1		
-	84	826802A14	1 TRIM HARNESS/RELAY ASSEME	1		
20	84	826802A	9 TRIM HARNESS	1		
21		828151A	1 RELAY ASSEMBLY	1		
22		828102	2 BRACKET	2		
23	25	818967	2 GROMMET	2		
24	23	818968	2 BUSHING	2		
25		NSS	2 DECAL-TRIM RELAY	2		6
26	10	824832	6 SCREW (M6 X 25)	2		