



23445

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		898101T59	BRACKET, Electrical	1		
2	10	823042	BOLT	5		
3	89	853809001	STARTER SOLENOID	1		4
4	89	898103T09	RELAY ASSEMBLY, Solenoid Swit	1		
5	87	898103T10	SWITCH ASSEMBLY, PTT Soleno	1		
6	85	853816004	BOOT, (Red)	4		
7	84	898101175	HARNESS, Solenoid Switch (Red)	2		
8	84	853740 8	CABLE, (Black)	2		
9	10	823042 7	BOLT	1		4
10		898101T60	COVER, Electrical Bracket	1		
11	23	95361	BUSHING	2		
12	10	16705 1	BOLT, (M6 x 20)	2		
13		898101T37	HOLDER, Cord	1		
14		898101094	HOLDER	1		
15	10	823042	BOLT	3		
16		898101134	ALARM, Over-Heat (Handle)	1		
17		898101118	SENSOR, MAT	1		
18	25	898101119	GROMMET, Mat Sensor	1		
19	32	898101072	HOSE, To Intake Manifold	1		
20	32	898101073	HOSE, To Intake Silencer	1		
21		898103005	VALVE ASSEMBLY	1		
22	10	16705	BOLT	3		
23	12	895118002	WASHER	6		
24	23	95286 8	COLLAR	3		
25		898101158	MOUNT, Rubber	3		
26		898101136	PLATE	1		
27	12	16826	WASHER	1		
28	11	40021 2	NUT, (M6)	1		
29	10	823042041	BOLT	2		4
-	50	899783A01	START KIT, Electric	1		