



17115

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	853805T03	STARTER MOTOR	1		4
2		851837	RUBBER MOUNT	1		4
3		898101186	BRACKET	1		4
4	10	823042052	BOLT	2		4
5	84	898101T06	CABLE, Battery	1		4
6	10	16211 1	BOLT	1		
7	87	17171 1	NEUTRAL SWITCH (Electric Hand	1		4
8		803841	ACTUATOR (Electric Handle)	1		4
9		804057001	PILOT LAMP	1		
10	85	853816002	BOOT	1		4
11	85	853816004	BOOT, (Red), Starter Solenoid	1		4
12		853740016	CABLE, Starter	1		4
13	85	853816003	BOOT, (Red), Starter Motor	1		4
14	87	803538	SWITCH	1		
15	84	898101101	CABLE, (With Grommet)	1		
16	84	898101144	HARNES, Extension-PTT	1		
17		898103T14	RECTIFIER	1		4
18	10	823042	BOLT	2		4
19		898101117	PLATE, Map Sensor	1		
20	10	823042040	BOLT	2		
21	12	895118002	WASHER	4		
22	23	95286 8	COLLAR	2		
23		898101158	MOUNT, Rubber	2		
24		898101116	SENSOR, MAP	1		
25	10	824832 4	SCREW, (M6 x 16)	1		
26	54	95224	CLIP	2		
27	32	898101103	HOSE	1		
28		851846001	SENSOR, Water Temperature	1		
29	25	16181 1	O-RING	1		
30	84	898101077	CABLE, Fuse	1		4
31	88	853814002	FUSE, (20 Ampere)	2		4
32	19	853994	TERMINAL PLUG	1		
33	10	823042 11	BOLT	2		4
34	87	853820A02	START SWITCH	1		4
-	50	899783A01	START KIT, Electric	1		