



3626

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	900	835430A04	CYLINDER HEAD	1	5
2	27	850836002	GASKET	1	5,2
3	17	16119	PIN, Dowel	4	5
4	10	855677002	BOLT	8	5
5	10	853531001	BOLT, Cylinder Head	3	5
6	12	895106	WASHER, Cylinder Head Cover	3	5
7	22	95368	3 PLUG	1	5
8	27	95220	GASKET	1	5
9	32	851848009	HOSE, Rubber	1	
10	22	812960	3 NIPPLE	1	
11	33	803507	SPARK PLUG, (NGK#DCPR6E) (N	3	
12		853756001	PLATE	1	5
13	10	16828	BOLT	1	5
14	32	812940006	PIPE, Oil, To Air Silencer	1	
15	54	803525001	CLIP	3	
16		834954002	COVER, Cylinder Head	1	5
17	10	16830A	1 SCREW KIT	8	5
18		859578A02	OIL FILLER CAP	1	5
19	25	803513007	O-RING	1	5,2
20	54	95306	CLAMP	1	5
21	27	803508018	GASKET	1	5,2
22		834974001	PLATE, Breather	1	5
23	10	823031016	SCREW	7	5
24	32	812940007	HOSE, Rubber, To Engine Base	1	
-	27	835427A05	GASKET SET, Powerhead	1	
-		895188A05	POWERHEAD	1	