



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		850838002	VALVE, Intake	3		5
2		850839002	VALVE, Exhaust	3		5
3	26	822647001	SEAL, Intake (Black)	3		5
4	26	822647002	SEAL, Exhaust (Green)	3		5
5	24	803554 4	SPRING	6		5
6		803598	SEAT	6		5
7		803555	RETAINER	6		5
8	28	803556	COTTER	12		5
9		850841003	ARM, Rocker	6		5
10	10	825046001	ADJUSTING SCREW	6		5
11	11	826150001	ADJUSTING NUT	6		5
12		850842002	SHAFT, Rocker	1		5
13		850842003	SHAFT, Rocker	1		5
14	10	823042036	BOLT	2		5
15		825451001	COLLAR	1		5
16	24	825452002	SPRING	3		5
17	24	825453001	SPRING	3		5
18	12	895118001	WASHER	6		5
-		895188A05	POWERHEAD	1		