



B-11

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		99702A 3	ADAPTOR PLATE ASSEMBLY (ME	1		
1		99702A 4	ADAPTOR PLATE ASSEMBLY (ME	1		
2		96248A 1	HOUSING ASSEMBLY,WATER TU	1		
3	26	25329	SEAL,WATER TUBE	1		2
4	23	96247	SPACER,WATER TUBE	1		
5	10	40003 5	SCREW,HOUSING TO ADAPTOR	2		
6	27	41670	GASKET,ADAPTOR PLATE	1		2
7		87357	SEAL,ADAPTOR PLATE	1		
11	32	85116	WATER TUBE,SHORT SHAFT	1		
11	32	86292	WATER TUBE,LONG SHAFT	1		
12	1588	8747A 1	HOUSING ASSEMBLY,SHORT SH-	1		
12	1591	8749A 1	HOUSING ASSEMBLY,LONG SHA	1		
13	27	43337	GASKET,DRIVE SHAFT HOUSIN	1		2
14	10	40003 60	SCREW,DRIVE SHAFT HOUSING	6		
15	12	40023 17	WASHER,DRIVE SHAFT HOUSIN	6		