



| Parts List |       |          |                             |   | Qty | Comment | Footnote |
|------------|-------|----------|-----------------------------|---|-----|---------|----------|
| Ref        | Class | Part     | Description                 |   |     |         |          |
| 1          |       | 62351A   | RECTIFIER ASSEMBLY          | 1 |     |         |          |
| 2          | 10    | 48409    | SCREW, RECTIFIER TO CYLINDE | 2 |     |         |          |
| 3          | 11    | 45076    | NUT, RECTIFIER TERMINALS    | 3 |     |         |          |
| 4          | 89    | 91975    | STARTER SOLENOID            | 1 |     |         |          |
| 5          | 10    | 40001 68 | SCREW, STARTER SOLENOID TI  | 2 |     |         |          |
| 6          | 11    | 26419    | NUT, STARTER SOLENOID TERM  | 2 |     |         |          |
| 7          | 11    | 64015    | NUT, STARTER SOLENOID TERM  | 2 |     |         |          |
| 8          | 84    | 88809A 5 | WIRE ASSEMBLY, YELLOW       | 1 |     |         |          |
| 9          | 84    | 88439A 8 | BATTERY WIRE ASSEMBLY, REC  | 1 |     |         |          |
| 9          | 84    | 88439A 6 | BATTERY WIRE ASSEMBLY, BLA  | 1 |     |         |          |
| 10         | 84    | 92436A 3 | WIRING HARNESS ASSEMBLY, E  | 1 |     |         |          |
| 11         | 88    | 95085    | FUSE                        | 1 |     |         |          |
| 12         |       | 92439    | BRACKET, WIRING HARNESS     | 1 |     |         |          |
| 13         | 10    | 40003 27 | SCREW, BRACKET              | 1 |     |         |          |
| 14         | 11    | 40021 2  | NUT, BRACKET SCREW          | 1 |     |         |          |
| 15         | 54    | 32779    | CLAMP, WIRING HARNESS       | 1 |     |         |          |
| 16         | 54    | 55098    | CLAMP, WIRING HARNESS       | 1 |     |         |          |
| 17         |       | 86704A 2 | STATOR ASSEMBLY, AUXILLARY  | 1 |     |         |          |
| 18         | 10    | 40001 23 | SCREW, STATOR ATTACHING (3  | 3 |     |         |          |
| 19         |       | 94301A 1 | PLATE ASSEMBLY, CHOKE KNOE  | 1 |     |         |          |
| 20         | 10    | 95088    | SCREW, PLATE TO SOLENOID    | 2 |     |         |          |
| 21         |       | 95020    | LEVER, CHOKE                | 1 |     |         |          |
| 22         | 53    | 95019    | RETAINING RING, CHOKE LEVEF | 1 |     |         |          |
| 23         | 89    | 94973A 3 | SOLENOID ASSEMBLY           | 1 |     |         |          |
| 24         | 18    | 21071    | COTTER PIN, CHOKE LEVER TO  | 1 |     |         |          |
| 25         | 50    | 90983A 1 | STARTER MOTOR ASSEMBLY      | 1 |     |         |          |
| 26         |       | 96561    | DRIVE KIT                   | 1 |     |         |          |
| 27         |       | 96562    | DRIVE                       | 1 |     |         |          |
| 28         |       | 96563    | END CAP                     | 1 |     |         |          |
| 29         |       | 96565    | ARMATURE                    | 1 |     |         |          |
| 30         |       | 96564    | END CAP, COMMUTATOR W/S     | 1 |     |         |          |
| 31         | 10    | 96566    | THRU BOLT                   | 1 |     |         |          |
| 32         | 10    | 40001149 | SCREW, STARTER MOTOR ATT    | 2 |     |         |          |