



| Parts List |       |          |                            |     |         |          |
|------------|-------|----------|----------------------------|-----|---------|----------|
| Ref        | Class | Part     | Description                | Qty | Comment | Footnote |
| 1          |       | 62351A   | RECTIFIER ASSEMBLY         | 1   |         |          |
| 2          | 10    | 48409    | SCREW,RECTIFIER TO CYLINDE | 2   |         |          |
| 3          | 11    | 45076    | NUT,RECTIFIER TERMINALS    | 3   |         |          |
| 4          | 89    | 96054    | STARTER SOLENOID           | 1   |         |          |
| 5          | 10    | 40001 68 | SCREW,STARTER SOLENOID TC  | 2   |         |          |
| 6          | 11    | 26419    | NUT,STARTER SOLENOID TERM  | 2   |         |          |
| 7          | 11    | 64015    | NUT,STARTER SOLENOID TERM  | 2   |         |          |
| 8          | 84    | 88809A   | WIRE ASSEMBLY,YELLOW       | 1   |         |          |
| 9          | 84    | 88439A   | BATTERY WIRE ASSEMBLY,RED  | 1   |         |          |
| 9          | 84    | 88439A   | BATTERY WIRE ASSEMBLY,BLAI | 1   |         |          |
| 10         | 84    | 92436A   | WIRING HARNESS ASSEMBLY,E  | 1   |         |          |
| 11         | 88    | 95085    | FUSE                       | 1   |         |          |
| 12         |       | 92439    | BRACKET,WIRING HARNESS     | 1   |         |          |
| 13         | 10    | 40003 27 | SCREW,BRACKET              | 1   |         |          |
| 14         | 11    | 40021 2  | NUT,BRACKET SCREW          | 1   |         |          |
| 15         | 54    | 32523    | CLAMP,WIRING HARNESS       | 1   |         |          |
| 16         | 54    | 55098    | CLAMP,WIRING HARNESS       | 1   |         |          |
| 17         |       | 86704A   | STATOR ASSEMBLY,AUXILIARY  | 1   |         |          |
| 18         | 10    | 40001 23 | SCREW,STATOR ATTACHING(30  | 3   |         |          |
| 19         | 50    | 90983A   | STARTER MOTOR ASSEMBLY     | 1   |         |          |
| 20         |       | 96561    | DRIVER KIT                 | 1   |         |          |
| 21         |       | 96562    | DRIVE                      | 1   |         |          |
| 22         |       | 96563    | DRIVE                      | 1   |         |          |
| 23         |       | 96563    | ARMATURE                   | 1   |         |          |
| 24         |       | 96564    | END CAP,COMMUTATOR W/SF    | 1   |         |          |
| 25         | 10    | 96566    | THRU BOLT                  | 1   |         |          |
| 26         | 10    | 40001149 | SCREW,STARTER MOTOR ATTA   | 2   |         |          |