



SOLENOID PLATE

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		858366T	2 PLATE	1		
2	89	817109A	2 SOLENOID ASSEMBLY, (#10-32 /	1		
3	25	822179	GROMMET	2		
4	10	821291	25 SCREW, (M6 x 25)	5		
5	23	818968	BUSHING	2		
6		882751A	1 RELAY ASSEMBLY	3		
7		NSS	NOT SOLD SEPARATE, Decal	3		
8		828102	BRACKET	3		
9	23	818968	BUSHING	3		
10	25	818967	GROMMET	3		
11	84	880005T	2 ENGINE HARNESS	1	SN# 0T598999 & Below	
11	84	880005T	2 ENGINE HARNESS	1	SN# 0T599000 & Up	
12	88	832969	20 FUSE, Yellow - 20 Ampere	3		
12	88	832969	5 FUSE, Tan - 5 Ampere	1		
13		858754	COVER, Fuse	1		
-	84	878073A	2 HARNESS (TPS)	1		
-	84	879964A	2 HARNESS END, Crank Position	1		
-	84	881262A	2 HARNESS END, Alternator	1		
14	10	821291	14 SCREW, (M6 x 14)	1		
15	54	55098	J CLIP	1		
16	84	882830A	1 CABLE ASSEMBLY	1	(225) SN# 0T467442 & Up	
16	84	882830A	1 CABLE ASSEMBLY	1	(250) SN# 0T467335 & Up	
17	10	821300	12 SCREW, (M6 x 12)	3		
18	84	819514T	16 TRIM HARNESS	1	SN# 0T598999 & Below	
18	84	819514T	18 TRIM HARNESS	1	SN# 0T599000 & Up	
19	84	859244T	1 DIGITAL ADAPTER HARNESS	1	(225) SN# 0T467442 & Up	
19	84	859244T	1 DIGITAL ADAPTER HARNESS	1	(250) SN# 0T467335 & Up	
20	84	878231A	6 HARNESS ASSEMBLY, Fuse (100	1	SN# 0T599000 & Up	
21	12	29245	WASHER, (.281 x .500 x .060)	1		
22	11	813938	CAPNUT, (#10-32)	2		
23	11	68292	NUT, (.312-18)	2		
24	11	45076	NUT, (#10-32) (BRASS)	2		
25	13	53166	LOCKWASHER, (.312)	2		
26	54	858755	CLIP, (1.00)	1		
27	54	828991	CLIP	1		
28		88555721S	PCM	1	(200)	
28		85961047S	PCM	1	(225)	
28		85961017S	PCM	1	(3L WORK)	
28		85961048S	PCM	1	(250)	
29	10	821300	25 SCREW, (M6 x 25)	3		
30	23	858954	BUSHING	2		