



2376

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	1689	842739T02	GEAR HOUSING-COMPLETE	1		
1	1689	842739T03	GEAR HOUSING, Basic	1		
2		823903	SHIFT CRANK	1		
3		19755T 7	SPOOL ASSEMBLY	1		
4		NSS	Not Sold Separate, Shift Spool	1		
5		NSS	Not Sold Separate, Sleeve	1		
6		NSS	Not Sold Separate, Cotter Pin	1		
7	15	47397A 1	SHIM SET	AR		
8	43	828168T 3	GEAR SET, Forward/Pinion (12/21)	1		
9	31	828437A 2	BEARING ASSEMBLY	1		
10		NSS	Not Sold Separate, Cup	1		
11	31	30895T	ROLLER BEARING	1		
12	53	856823	RETAINING RING	1		
13	52	848878T	CLUTCH	1		
14	17	78909	DETENT PIN	2		
15	17	848838	CROSS PIN	1		
16	24	78962	SPRING	2		
17	44	848829	PROPELLER SHAFT	1		
18	43	848881A 1	GEAR, Reverse (12/21)	1		
19	23	824108 1	THRUST SPACER	1		
20	30	88957T	BALL BEARING	1		
21		68100 1	RING-THRUST	1		
22	25	31534	O RING	1		15
23		848840T 1	BEARING CARRIER	1		
24	31	817072	ROLLER BEARING	1		
25	53	817071	SNAP RING	1		
26	26	815565	SEAL	2		
27	28	30281A 1	KEY	1		
28	22	67892A 1	PLUG KIT, Fill/Drain (Magnetic)	1	SN# 0T979999 & Up	
28	22	67892A05	PLUG KIT, Drain	1	SN# 0T980000 & Up	
29	12	<a href="#">19183 3</a>	SEAL	1		15
30	14	79447	TAB WASHER	1		
31		79448	RETAINER	1		
32	10	806327	SCREW, (.437-14 x 1.750)	1		
33		<a href="#">76214Q 5</a>	ANODIC PLATE ASSEMBLY	1		
-	26	816575A 4	GEAR HOUSING SEAL KIT	1		