



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1623	822442A83	GEAR HOUSING	1	BASIC-BLACK	
1	1623	822442A84	GEAR HOUSING	1	BASIC-GRAY	
1	1623	822442A79	GEAR HOUSING	1	BASIC-WHITE	
45		823903	SHIFT CRANK	1		
46		19755A 7	SHIFT SPOOL KIT	1		
47	15	44491A 1	SHIM	AR		6
48		828830A 2	BEARING ADAPTOR ASSEMBLY	1		
49	31	814653	ROLLER BEARING	1		
50	12	815481	THRUST WASHER	1		
51	31	815480	THRUST BEARING	1		
52	43	828696A 2	REVERSE GEAR	1	(1.75:1 - 12/21)	
53	31	15844	ROLLER BEARING	1		
54	24	30893	SPRING	1		
55	52	828288	SLIDING CLUTCH	1		
56	17	30632	CROSS PIN	1		
57	17	828356	DETENT PIN	1		
58	44	824111	PROPELLER SHAFT	1		
59	43	828695A 1	FORWARD GEAR	1	(INCLUDES PINION) (1.75:1 - 12/	
60	23	17615 14	SPACER SHIM .206 IN.	AR		6
60	23	17615 15	SPACER SHIM .208 IN.	AR		6
60	23	17615 16	SPACER SHIM .210 IN.	AR		6
60	23	17615 17	SPACER SHIM .212 IN.	AR		6
60	23	17615 18	SPACER SHIM .214 IN.	AR		6
60	23	17615 19	SPACER SHIM .216 IN.	AR		6
60	23	17615 20	SPACER SHIM .218 IN.	AR		6
60	23	17615 21	SPACER SHIM .220 IN.	AR		6
60	23	17615 22	SPACER SHIM .222 IN.	AR		6
60	23	17615 23	SPACER SHIM .224 IN.	AR		6
60	23	17615 24	SPACER SHIM .226 IN.	AR		6
60	23	17615 25	SPACER SHIM .228 IN.	AR		6
60	23	17615 26	SPACER SHIM .230 IN.	AR		6