



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	400	891644A04	CRANKSHAFT	1		5
2	23	895715T01	BEARING, Crankshaft-Upper	12/AR	(Green)	5
2	23	895715T02	BEARING, Crankshaft-Upper	12/AR	(Navy Blue)	5
2	23	895715T03	BEARING, Crankshaft-Upper	12/AR	(White)	5
2	23	895715T04	BEARING, Crankshaft-Upper	12/AR	(Orange)	5
3	23	895716T01	THRUST BEARING, Crankshaft-Lc	2/AR	(Green)	5
3	23	895716T02	THRUST BEARING, Crankshaft-Lc	2/AR	(Navy Blue)	5
3	23	895716T03	THRUST BEARING, Crankshaft-Lc	2/AR	(White)	5
3	23	895716T04	THRUST BEARING, Crankshaft-Lc	2/AR	(Orange)	5
4	26	880525 1	SEAL, Top Main Bearing	1		2,5
5	28	91800	KEY, Woodruff	1		5
6	19	885348	CAP, Flywheel Bolt	1		5
7		880556	CHAIN	1		5
8	662	881210T02	CONNECTING ROD	6		5
9	10	884441	BOLT	12		5
10	23	881211	BUSHING	6		5
11	23	892005A01	BEARING, Connecting Rod	12/AR	(Blue)	5
11	23	892005A02	BEARING, Connecting Rod	12/AR	(White)	5
11	23	892005A03	BEARING, Connecting Rod	12/AR	(Orange)	5
12	700	896092T01	PISTON ASSEMBLY	6		5
13	39	881180A01	RING SET, Piston	1		5
14		NSS	NOT SOLD SEPARATE, Piston	6		5
15		NSS	NOT SOLD SEPARATE, Piston	6		5
16		NSS	NOT SOLD SEPARATE, Piston F	6		5
17	40	881184	CIRCLIP	12		5
18	200	888983T02	FLYWHEEL	1		5
19	10	880515	BOLT, (M20 x 68)	1		5
20	12	880517	WASHER	1		5
-	27	880552A05	GASKET SET, Powerhead	1		
-	61	895247A05	POWERHEAD ASSEMBLY	1		