



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		92459A 4	HYDRAULIC PUMP (DESIGN I)	1		
2		90318	BRACKET (DESIGN I)	1		
3	10	90285	SCREW (5/8") (DESIGN I)	1		
4	12	56720	WASHER (DESIGN I)	1		
5	11	34059	NUT (DESIGN I)	2		
8	84	79138A 9	BATTERY CABLE (BLACK - NEGA	1		
9	54	55098	J-CLIP	1		
10	84	79147A 3	NECESS ASSEMBLY	1		
11	88	79091	FUSE	1		
12	84	95084A 3	CABLE ASSEMBLY	1		
13	89	96158	STARTER SOLENOID	2		
14		88075	RETAINER	1		
15	10	41508	SCREW (3/8")	4		
16	11	26419	NUT (#8-32)	4		
17		94275	CONNECTOR	1		
18	13	26992	LOCKWASHER (1/4")	5		
19	11	94330	NUT (1/4-20)	4		
20	88	79023A10	FUSE (110 AMP)	1		
21	12	96457	WASHER	1		
22	11	21825	NUT	1		
23	84	86322A15	WIRE (BLACK)	1		
24	84	79139A12	BATTERY CABLE (RED-POSITIVE	1		
25		87762	BRACKET	1		
26	10	31830	BOLT (3-1/2")	2		
27	13	58643	LOCKWASHER	2		
28	11	46335	NUT	2		
29		87760	PLATE	1		
30	10	39349	SCREW (3/4")	1		
31	13	26993	LOCKWASHER	1		
32	10	90271	SCREW (5/8")	2		
33	13	58643	LOCKWASHER	2		
34	85	96535	BOOT	1		
35	10	48409	SCREW	1		
36	32	96993	HYDRAULIC HOSE (PORT)	1		
36	32	96994	HYDRAULIC HOSE (STARBOARD	1		
37	32	89024	HYDRAULIC HOSE (PORT)	1		
37	32	89023	HYDRAULIC HOSE (STARBOARD	1		
38	25	12602	GROMMET	2		
39	22	87207	CONNECTOR	1		
40		87871	COVER	1		
41	27	82775	GASKET	1		