



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1659	9554A16	GEAR HOUSING, COMPLETE (X-L	1		
-	1659	9554A17	GEAR HOUSING, COMPLETE (X	1		
-	1659	9554A18	GEAR HOUSING, COMPLETE (X-L	1		
-	1659	9554A19	GEAR HOUSING, COMPLETE (X	1		
1	1659	9554A23	GEAR HOUSING (BLACK)	1		
1	1659	9554A24	GEAR HOUSING (GRAY)	1		
39		78956	SHIFT CAM	1		
40		17264F 2	TRIM TAB	1		
41	10	90042	SCREW	1		
42		89594A 1	CAM FOLLOWER	1		
43		88523	CLUTCH ACTUATOR ROD	1		
44	25	88579	SPRING	2		
45	12	78910	WASHER	AR		8
46	17	78906	PIN	1		
47		815362A 1	BEARING ADAPTOR ASSEMBL	1		
48	31	814653	ROLLER BEARING	1		
49	12	815481	THRUST WASHER	1		
50	31	815480	THRUST BEARING	1		
51		N. S. S.	REVERSE GEAR (PART OF 43-E	1		
52	31	815482	ROLLER BEARING	1		
53	17	78909	DETENT PIN	2		
54	52	823580	RATCHET	1		
55	17	78905	CROSS PIN	1		8
56	24	78962	SPRING	2		
57	43	812975A 1	GEAR SET	1		
58	23	17615 14	SPACER SHIM .206"	AR		8
58	23	17615 15	SPACER SHIM .208"	AR		8
58	23	17615 16	SPACER SHIM .210"	AR		8
58	23	17615 17	SPACER SHIM .212"	AR		8
58	23	17615 18	SPACER SHIM .214"	AR		8
58	23	17615 19	SPACER SHIM .216"	AR		8
58	23	17615 20	SPACER SHIM .218"	AR		8
58	23	17615 21	SPACER SHIM .220"	AR		8
58	23	17615 22	SPACER SHIM .222"	AR		8
58	23	17615 23	SPACER SHIM .224"	AR		8
58	23	17615 24	SPACER SHIM .226"	AR		8
58	23	17615 25	SPACER SHIM .228"	AR		8
58	23	17615 26	SPACER SHIM .230"	AR		8
59	31	15841	ROLLER BEARING	1		
60	12	17616	THRUST RING	1		
61	25	21524	O-RING	1		1