



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1659	9554A12	GEAR HOUSING, COMPLETE (LO	1	
-	1659	9554A 6	GEAR HOUSING, COMPLETE (X-L	1	
-	1659	9554A 7	GEAR HOUSING, COMPLETE (XX	1	
-	1659	9554A22	GEAR HOUSING, COMPLETE (LO	1	
-	1659	9554A10	GEAR HOUSING, COMPLETE (X-L	1	
-	1659	9554A11	GEAR HOUSING, COMPLETE (XX	1	
1	1659	9554A23	GEAR HOUSING- CASTING #16	1	
1	1659	9554A 9	GEAR HOUSING- CASTING #16	1	
1	1659	9554A23	GEAR HOUSING -CASTING #16	1	
1	1659	9554A24	GEAR HOUSING-CASTING #16	1	
39		78956	SHIFT CAM	1	
40		17264F 2	TRIM TAB	1	
41	10	90042	SCREW	1	
42		89594A 1	CAM FOLLOWER	1	
43		88523	ROD (USE W/ G/H CASTING #	1	
43		816519	ROD (USE W/ G/H CASTING #	1	
44	17	78906	PIN	2	
45	124	88579	SPRING (USE W/ G/H CASTING	2	
45	24	88579	SPRING (USE W/ G/H CASTING	1	
46	12	78910	WASHER	1	
47	15	47397A 1	SHIM	AR	8
48	31	35928A 1	TAPERED ROLLER BEARING A	1	
49	43	17064A 2	GEAR ST (USE W/ G/H CASTING	1	
49	43	17064A 5	GEAR SET (USE W/ G/H CASTING	1	
50	31	30895	ROLLER BEARING	1	
51	52	823580	RATCHET	1	
52	17	78909	DETENT PIN	2	
53	17	78905	CROSS PIN	1	
54	24	78962	SPRING	2	
55	44	93848	PROPELLER SHAFT	1	
56		N.S.S.	REVERSE GEAR (PART OF 43-1	1	
57		68100 1	THRUSTING RING	1	
58	30	88957A 1	BALL BEARING	1	
59	25	31534	O-RING	1	1
60		88603A 4	CARRIER (USE W/ CASTING	1	
60		813082A 1	CARRIER ( USE W/ CASTING	1	
61	31	30956	ROLLER BEARING	1	
62	26	76868	OIL SEAL	2	
63	28	30281	KEY	1	
64	14	79447	TAB WASHER	1	
65		79448	COVER	1	