



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		14460	OIL PUMP	1		
2	10	34994	SCREW (1")	1		4
2	10	73013	SCREW (1-1/2")	1		4
3		19385 16	LINK	1		
4		14525A 3	ADAPTOR ASSEMBLY	1		
5	43	41083	DRIVEN GEAR	1		4
6	25	11379	O-RING	1		
7	54	816311	CLAMP	AR		8
8	32	43016 25	TUBING	1		
9		15136	OIL RESERVOIR	1		
10	10	63328	SCREW	2		
11	13	53166	LOCKWASHER	3		
12	12	36042	WASHER	6		
13	12	67264	WASHER	6		
14	23	67268	SPACER	3		
15	23	14680	SPACER	3		
16	25	48462	O-RING	2		
17	36	43300A 5	CAP ASSEMBLY	1		
18	27	43307	GASKET	1		
19		99022A 1	FLOAT ASSEMBLY	1		
20	11	99265	PUSHNUT	1		
21	32	99127109	TUBING	1		
22	54	41582 3	CLAMP	2		
23	32	99127109	TUBING	1		
24	22	42425	FITTING	1		
25	32	99128 78	HOSE	1		
26	32	99127109	HOSE	1		
27	1257	8742 1	OIL TANK	1		
28	36	43298A 2	CAP ASSEMBLY	1		
29	25	11332	O-RING	1		
30		43295A 5	ADAPTOR HOUSING ASSEMBLY	1		
31	25	11332	O-RING- OLD DESIGN	1		
32	32	99802	TUBE- OLD DESIGN	1		
33		12540A 4	HOUSING ASSEMBLY	1	QUICK DISCONNECT- OLD DESI	
34	32	99439	HOSE- OLD DESIGN	1		
35		12540A 3	HOUSING- OLD DESIGN	1		
36		12242A 1	LATCH- OLD DESIGN	1		
30		816190A 3	ADAPTOR HOUSING ASSEMBLY	1		
31	25	11332	O-RING- NEW DESIGN	1		
32	32	99802	TUBE- NEW DESIGN	1		
34	32	99439	HOSE- NEW DESIGN	1		