



| Parts List | | | | | |
|------------|-------|----------|----------------------------|--------|----------|
| Ref | Class | Part | Description | Qty | Footnote |
| 1 | | 99702A 3 | ADAPTOR PLATE ASSEMBLY (18 | 1 | |
| 1 | | 99702A 6 | ADAPTOR PLATE ASSEMBLY (20 | 1 | |
| 2 | | 96248A 1 | HOUSING ASSEMBLY, WATER T | 1 | |
| 3 | 26 | 25329 | SEAL, WATER TUBE | 1 | 2 |
| 4 | | 96247 | SPACER, WATER TUBE | 1 | |
| 5 | 10 | 40003 5 | SCREW, HOUSING TO ADAPTOF | 2 | |
| 6 | 27 | 41670 | GASKET, ADAPTOR, PLATE | 1 | 2 |
| 7 | | 87357 | SEALM ADAPTOR PLATE | 1 | |
| 8 | | 41211 | BRACKET, UPPER MOUNT | 2 | |
| 9 | 10 | 40007128 | SCREW, UPPER MOUNT BRACKI | 2 | |
| 10 | 12 | 29245 | WASHER, UPPER MOUNT BRAC | 2 | |
| 11 | 32 | 85116 | WATER TUBE (SHORT SHAFT) | 1 | |
| 11 | 32 | 86292 | WATER TUBE (LONG SHAFT) | 1 | |
| 12 | 1588 | 9097A 2 | HOUSING ASSEMBLY (SHORT SH | 1 | |
| 12 | 1591 | 9098A 2 | HOUSING ASSEMBLY (LONG SH | 11588- | |
| 12 | | 3 | HOUSING ASSEMBLY (SHORT SH | 1 | |
| 12 | 1591 | 9098A 3 | HOUSING ASSEMBLY (LONG SH | 1 | |
| 13 | 27 | 43337 1 | GASKET, DRIVER SHAFT HOU | 1 | 2 |
| 14 | | 14534 | COVER, IDLE RELIEF | 1 | |
| 15 | 127 | 14621 | GASKET, COVER | 1 | 2 |
| 16 | 10 | 14742 | SCREW, COVER | 1 | |
| 17 | 10 | 40003 60 | SCREW, DRIVE SHAFT HOUSIN | 6 | |
| 18 | 12 | 40023 17 | WASHER, DRIVE SHAFT HOUSIN | 6 | |
| - | 27 | 41499A87 | GASKET SET | | |