



|     |       |          |                              | Parts List |         |          |
|-----|-------|----------|------------------------------|------------|---------|----------|
| Ref | Class | Part     | Description                  | Qty        | Comment | Footnote |
| 1   | 1390  | 8888A 7  | CARBURETOR (MANUAL - WMC)    | 1          |         |          |
| 1   | 1390  | 8676A 9  | CARBURETOR (ELECTRIC - WMC)  | 1          |         |          |
| 2   | 1395  | 9640     | THROTTLE VALVE               | 1          |         |          |
| 3   | 1395  | 9167     | THROTTLE SHAFT (WMC - 13/14) | 1          |         |          |
| 3   | 1395  | 9695     | THROTTLE SHAFT (WMC-13A/     | 1          |         |          |
| 4   | 1395  | 9164     | FUEL BOMB                    | 1          |         |          |
| 5   | 1395  | 9169     | FLOAT                        | 1          |         |          |
| 6   | 1395  | 9170     | VALVE, INLET NEEDLE          | 1          |         |          |
| 7   | 1399  | 5317     | JET, MAIN FUEL (.046)        | 1          |         |          |
| 8   | 1395  | 9171     | PLUG, JET RETAINER           | 1          |         |          |
| 9   | 1395  | 9165     | COVER, DIAPHRAGM             | 1          |         |          |
| 10  | 1395  | 9174     | SCREW, DIAPHRAGM COVER       | 4          |         |          |
| 10  | 1395  | 9697     | SCREW, DIAPHRAGM COVER       | 4          |         |          |
| 11  |       | 15827A 1 | BODY, FUEL PUMP              | 1          |         |          |
| 12  | 1395  | 9643     | SCREW, FUEL PUMP COVER       | 5          |         |          |
| 13  | 1395  | 9637     | COVER, FUEL PUMP             | 1          |         |          |
| 14  | 1395  | 9535     | PLUG                         | 1          |         |          |
| 15  | 1395  | 9645     | GASKET/DIAPHRAGM KIT         | 1          |         |          |
| 16  | 1395  | 9644     | REPAIR PARTS KIT             | 1          |         |          |
| 17  | 1395  | 9699     | PLATE, COVER (MANUAL)        | 1          |         |          |
| 18  | 1395  | 9182     | ELECTRIC CHOKE (ELECTRIC -   | 1          |         |          |
| 18  | 1395  | 9701     | ELECTRIC CHOKE (ELECTRIC -   | 1          |         |          |
| 19  | 1395  | 9172     | SCREW, COVER PLATE (WMC)     | 2          |         |          |
| 19  | 1395  | 9696     | SCREW, COVER PLATE (WMC)     | 2          |         |          |
| 20  | 27    | 41449    | GASKET, CARBURETOR           | 1          |         | 2        |
| 21  |       | 41717    | BRACKET, PRIMER              | 1          |         |          |
| 22  | 10    | 40001 8  | SCREW, BRACKET TO CARBURE    | 2          |         |          |
| 23  |       | 42515A 1 | LEVER ASSEMBLY, FAST IDLE    | 1          |         |          |
| 24  |       | 41703    | LEVER, PRIMER                | 1          |         |          |
| 25  |       | 12733    | IDLE WIRE                    | 1          |         |          |
| 26  |       | 11024 2  | ACTUATOR, PRIMER             | 1          |         |          |
| 27  |       | 12654    | INSTRUCTION PLATE (MERCUR)   | 1          |         |          |
| 28  |       | 12653    | INSTRUCTION PLATE (MARINER)  | 1          |         |          |