



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	1648	7811A22	GEAR HOUSING ASSY, COMPLE	1		
-	1648	7811A23	GEAR HOUSING ASSY, COMPLE	1		
1	1648	7811A 9	GEAR HOUSING ASSEMBLY	1		
32	11	20696	NUT, PROPELLER SHAFT	1		
33	12	73672	WASHER, PROPELLER SHAFT	1		
34	43	90795	DRIVE GEAR	1		
35	14	79603	WASHER, SPECIAL - PROPELLI	1		
36	15	79602A 1	SHIM ASSEMBLY, PROPELLER	AR		5
37	53	79601	RETAINING RING	1		
38	24	91813	SPRING, CLUTCH	1		
39	44	93358	PROPELLER SHAFT	1		
40		77424	SPACER, PROPELER SHAFT	1		
41		99210A 1	BEARING CARRIER ASSEMBLY	1		
42	26	98309	OIL SEAL	1		4
43		75812	COVER, GEAR HOUSING	1		
44	25	68935	O RING, BEARING CARRIER	1		1
45	28	32003	KEY, BEARING CARRIER	1		
46		70588	THRUST HUB, FORWARD	1		
47	48	93357A10	PROPELLER ASSEMBLY	1		
48		93356	THRUST HUB, AFT	1		
49	11	35814	PROPELLER, NUT	1		
50	11	35814	NUT, DRIVE SHAFT HOUSING S1	1		