



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	87622	STARTER, RECOIL	1		
2	50	89141	ROPE, STARTER	1		
3		79470A 1	HANDLE AND RETAINER ASSE	1	STARTER ROPE	
4		93498A 1	BRACKET ASSEMBLY, FLYWHEE	1		
5		87934	LEG, BRACKET	1		
6	10	54615	SCREW, BRACKET AND LEG AT1	3		
7	11	28941	NUT, RECOIL STARTER ATTACH	4		
8	25	90329	GROMMET, BRACKET	2		
9		87886	CUP, STARTER	1		
10	256	7530	FLYWHEEL	1		
11	28	20094	KEY, FLYWHEEL DRIVE	1		
12	11	20696	NUT, FLYWHEEL TO CRANKSHA	1		
13	12	20346	WASHER, RECOIL STARTER STI	4		
14		88305	HOUSING, IGNITION MODULE	1		
15		88182	IGNITION MODULE	1		
16		88306	RETAINER, IGNITION MODULE	1		
17	10	88307	SCREW, WIRE TO HOUSING (5/1	1		
18		88188	BUTTON, FRICTON-HOUSING	1		
19	24	90304	SPRING, COMPRESSION-FRICTIC	1		
20	10	88186	SCREW, SET-FRICTION BUTTON	1		
21		87885	IGNITION COIL	1		
22	84	63212A 2	LEAD WIRE ASSEMBLY	1		
23	85	63709A 1	PROTECTOR ASSEMBLY, SPAF	1		
24	33	88088	SPARK PLUG (CHAMPION#L81Y)	1		
24	33	88090	SPARK PLUG (CHAMPION#QL81)	1	-CANADA AND BELGIUM	
25	10	60605	SCREW, IGNITION COIL (3/4")	2		
26		88221	TAB, IDLE STOP	1		