



- Loctite PST Pipe Sealant (92-809822)
- Loctite Master Gasket (92-12564-2)
- 2 Cycle Outboard Oil (92-13249A24)

- Perfect Seal (92-34227-1)
- Loctite 680 (92-809833)
- 2-4-C With Teflon (92-825407A12)

1314

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	890	821358A 5	CYLINDER BLOCK	1		3,1,4
2	22	32802 1	PIPE PLUG (1/8 HEX HEAD-BR/	2		1
3	17	824864	ROLL PIN (USE WHERE APPLIC	1		1
4	10	817427 80	SCREW (M8 X 80 HEX FLANGE	6		1
5		812888A 1	CARRIER ASSEMBLY	1		1
6	21	42657A 3	CHECK VALVE	1		1,4
7	21	828218	CHECK VALVE	1		1,4
8	22	65857	FITTING (BARBED-ELECTRIC)	1		
9	10	817427 40	SCREW (M8 X 40 HEX FLANGE	4		1
10	22	85439	CONNECTOR (MALE)	1		1
11	17	812870	PIN-CENTER MAIN	2		1
12	17	43044	DOWEL PIN	1		1
13	22	39072	PIPE PLUG (1/8 IN.-BRASS)	1		1
14	22	18598	PIPE PLUG (3/8-18)	1		1
15	22	15133	ELBOW	2		1
16	1171	9812A 4	END CAP	1		1
17	26	828932	OIL SEAL	1		1
18	26	41953	OIL SEAL	1		1
19	25	90011	O RING	1		2,1
20	10	817427 20	SCREW (M8 X 1.25 X 20 HEX FLA	3		1
.	27	822420A94	GASKET SET	1		
.		808569A97	POWERHEAD	1		4