



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		14360A43	FUEL PUMP ASSEMBLY	1		
2	21	42990A10	DIAPHRAGM KIT	1		2
3		NSS	RUBBER CHECK VALVE	2		5,6
4		NSS	CHECK VALVE	2		5,6
5		NSS	RETAINER	2		5,6
6		NSS	SPRING	1		5,6
7		NSS	CAP	1		5,6
8		NSS	SPRING	1		5,6
9		NSS	CAP	1		5,6
10		NSS	GASKET-BOOST	1		5,6
11	27	98769 1	GASKET	1		2,1,6
12		NSS	DIAPHRAGM	1		5,6
13		NSS	GASKET-PULSE	1		5,6
14		14430 3	BASE	1		
15		98775 2	PLATE	1		
16	10	821300 50	SCREW-PUMP TO CRANKCASE	2	(M6 X 1 X 50)	1
17	10	821045 40	SCREW-PUMP	2		
18	22	43335	FITTING	1		
19		816877 3	PRIMER BULB	1		4
20	32	99130122	HOSE (9-1/2 IN.)	2		
21	23	825381 15	SLEEVE	1		
22	32	830764	HOSE	1		
23	54	816311	STA-STRAP	AR		11
24	32	99128 78	HOSE (3-1/4 IN.)	1		
25	85	12096 6	INSULATOR	1		3
26	32	830765	HOSE (MOLDED)	1		
27	35	87946A14	FUEL FILTER	1		
28		822387	BRACKET	1		
29	11	40119 6	NUT (M6 X 1)	1		
30	32	830757 80	HOSE (14-1/4 IN.)	1		
31	22	816856A 1	FUEL CONNECTOR	1		
32	10	40003 32	SCREW	1		
-	27	822420A94	GASKET SET	1		
-		808569A97	POWERHEAD	1		4