



1290

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1682	821306T54	GEAR HOUSING ASSEMBLY-COM	1	(SHORT)	
-	1682	821306T17	GEAR HOUSING ASSEMBLY-COM	1	(LONG)	
1	1682	821306T12	GEAR HOUSING, (Basic)	1	(BASIC)	
39	17	821327	PIN, Dowel	2		
40	27	823942	GASKET	1		
41	32	821828	TUBE	1		
42	19	824928	PLUG, Rubber	1		
43		821829	SCREEN	1		
44		822157T 2	TRIM TAB	1		
45	10	824970 20	SCREW, (M8 x 20)	1		
46	12	72397	WASHER	1		
47	43	821315T 1	FORWARD GEAR ASSEMBLY, (1		
48	31	99328A 1	ROLLER BEARING ASSEMBL	1		
49		NSS	NOT SOLD SEPARATE, Cup	1		
50	31	41326	ROLLER BEARING	1		
51		821578	FOLLOWER, Cam	1		
52	24	826199 1	SPRING	1		
53	17	85093	PIN	1		
54	52	821314T	CLUTCH	1		
55	24	38114	SPRING	1		
56	44	821577 2	PROPELLER SHAFT	1		
57	43	821312T 1	REVERSE GEAR, (26 Teeth)	1		
58	30	20839T	BEARING	1		
59		19291A 3	BEARING CARRIER	1		
60	25	815460	O-RING	1		15
61	31	21700	ROLLER BEARING	1		
62	26	69188	OIL SEAL	1		15
63	26	69189	OIL SEAL	1		15
64	12	855941	WASHER	2		
65	10	855940 30	SCREW, (M8 x 30)	2		
66		822773 1	INSERT, Threaded	2		
67		NSS	NOT SOLD SEPARATE, Decal (2-	1		
68		73345A 1	THRUST HUB	1		
69	11	69578A 1	PROPELLER NUT	1		
70	14	76281	TAB WASHER	1		
71	10	40003 80	SCREW, (M10 x 45)	4		
72	12	856774	WASHER, (.406 x .750 x .105)	4		
73	19	95925	PLUG	1		
-		823547A 2	SEAL KIT	1		