



2532

Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|---------|----------------------------|-----|---------|----------|
| 52 | 91 | 14308T | BEARING RACE TOOL | 1 | | |
| 53 | 91 | 14309T | BEARING INSTALLATION | 1 | | |
| 54 | 91 | 14310T | WEAR SLEEVE INSTALLATION T | 1 | | |
| 55 | 91 | 14311A | BEARING, Pre-Load Tool | 1 | | |
| 56 | 91 | 78473 | BACKLASH INDICATOR TOOL | 1 | | |
| 57 | 91 | 31106T | MANDREL | 1 | | |
| 58 | 91 | 31108T | OIL SEAL DRIVER | 1 | | |
| 59 | 91 | 34569A | SLIDE HAMMER | 1 | | |
| 60 | 91 | 46086A | PULLER JAWS | 1 | | |
| 61 | 91 | 37350T | MANDREL | 1 | | |
| 62 | 91 | 56775T | DRIVESHAFT HOLDING TOOL | 1 | | |
| 63 | 91 | 58222A | DIAL INDICATOR KIT | 1 | | |
| 64 | 91 | 85716 | PULLER BOLT | 1 | | |
| 65 | 91 | 83155 | ADAPTER KIT | 1 | | |
| 66 | 91 | 83165T | PULLER ASSEMBLY | 1 | | |
| 67 | 91 | 856875A | BEARING INSTALLATION TOOL | 1 | | |