



16674

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		851873T03	POWER TRIM/TILT ASSEMBLY	1		
2		898101246	JOINT	1		
3	11	898101247	NUT	1		
4	26	898101248	SEAL	1		
5	25	898101249	O-RING	1		
6		898103T36	CYLINDER	1		
7	25	898101254	O-RING	1		
8		898103T37	TUBE, (Inner)	1		
9	25	898101255	O-RING	1		
10		898103T38	PISTON ROD ASSEMBLY	1		
11	25	898101250	O-RING	1		
12		898101251	PISTON	1		
13		898101252	RING	1		
14	25	898101253	O-RING	1		
15		898101115	MANUAL VALVE ASSEMBLY	1		
16		898101167	SEAL SET	1		
17	25	812641003	O-RING	1		
18	26	898101245	SEAL	1		
19	53	804027002	C RING	1		
20	25	803513009	O-RING	1		
21		898101213	VALVE SEAT	1		
22		898101005	BALL	1		
23	24	898101180	SEAT, Spring	1		
24	24	898101176	SPRING	1		
25	25	16131 4	O-RING	2		
26		898103T12	PUMP	1		
27		851877001	COUPLING	1		
28	10	851866 3	BOLT	3		
29	25	16131011	O-RING	1		
30		898103T31	MOTOR ASSEMBLY	1		
31	25	898101130	O-RING	1		
32		898103T15	RESEVOIR TANK, Reservoir	1		
33		898101024	CAP ASSEMBLY	1		
34	25	898101129	O-RING	1		
35	10	898101015	SCREW	2		
36	87	898103011	SWITCH, PTT	1		
37	25	898101145	O-RING	1		
38		896630	BRACKET, Switch	1		
39	10	824832 4	SCREW, (M6 x 16)	2		