



20518

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	200	898101T64	FLYWHEEL	1		
2	11	851832	NUT	1		
3	12	853991 1	WASHER	3		
4		898101T01	ALTERNATOR ASSEMBLY	1		
5	10	823042	BOLT	3		
6	54	95306	CLAMP	3		
7	19	898101138	PLUG	1		
8		898101T30	BRACKET, Coil	1		
9	10	823042 24	BOLT	3		
10		898101146	PULSER COIL	1		
11	10	823042067	SCREW	4		
12		898101147	PULSER COIL	1		
13	339	898103T	IGNITION COIL	3		
14	85	898101141	BOOT	3		
15	10	16705 1	BOLT, (M6 x 20)	3		
16	54	95306	CLAMP	2		
17		898101T56	ECU	1	(30)	
17		898101T57	ECU	1	(30 EU)	
17		898101T53	ECU	1	(25)	
17		898101T54	ECU	1	(25 EU)	
17		898101357	ECU	1	(25 Bodensee)	
18	19	898101139	PLUG	1		
19		898101050	BRACKET, ECU	1		
20	10	16832	BOLT, (M6 x 16)	2		
21	12	895118002	WASHER	2		
22	12	895118002	WASHER	6		
23	10	823042040	BOLT	3		
24	23	95286 8	COLLAR	3		
25		898101158	MOUNT, Rubber	3		
26	19	853994	TERMINAL PLUG	3		
27	84	898101T51	HARNESS, ECU	1	(Handle)	
27	84	898101T52	HARNESS, ECU	1	(Power Trim)	
28	54	898101111	STA-STRAP	4		
29	54	803563	CLAMP	1		