



A= To top carburetor
 B= to crankcase
 C= to oil pump fitting (REF. #36 on "Cylinder Block and Crankcase" section)
 D= TO INTAKE MANIFOLD FITTING (REF. #15 on "Induction Manifold and Reed Block" section)
 E= TO FITTING (REF. #15 on "Attenuator Plate" section)
 F = to oil pump outlet on "Induction Manifold and Reed Block" section

Loctite PST Pipe Sealant (92-809822)

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-		14360A43	FUEL PUMP ASSEMBLY	1		
1		NSS	FUEL PUMP	1		4
2	21	42990A10	DIAPHRAGM KIT	2		1
3		NSS	DIAPHRAGM	1		4,7
4		NSS	RUBBER CHECK VALVE	2		4,7
5		NSS	RETAINER	2		4,7
6		NSS	SPRING	1		4,7
7		NSS	CAP	1		4,7
8		NSS	SPRING	1		4,7
9		NSS	CAP	1		4,7
10		NSS	DIAPHRAGM	1		4,7
11	27	98769 1	GASKET	1		2,7
12		NSS	GASKET-BOOST	1		4,7
13		NSS	GASKET-PULSE	1		4,7
14		98775 2	PLATE	1		
15	22	43335	FITTING	2		2
16	10	821045 40	SCREW-FUEL PUMP (M5 X 40)	2		
16	10	821300 50	SCREW- PUMP TO CRANKCASE	2		
17		14430 3	BASE	1		
18	32	831949	HOSE	1		
19	35	816296 1	FUEL FILTER	1		
20	32	830761	FUEL LINE	1		
21	54	816311	STA-STRAP	AR		10
22	32	830757 80	HOSE (1-1/2 IN.)	1	40	
23	32	830757 80	HOSE (1-1/2 IN.)	1	40	
24	22	818992	WYE CONNECTOR	1	40	
25	32	823813 35	HOSE (2 IN.)	1	40	3
22	32	830757 80	HOSE (1-1/4 IN.)	1	50	
23	32	830757 80	HOSE (1-1/4 IN.)	1	50	
24	22	818993	TEE CONNECTOR	1	50	
25	32	823813 35	HOSE (1-1/2 IN.)	1	50	3
26	32	830757 80	HOSE (22 IN.)	1		
27	22	818994 1	CHECK VALVE	1		
28	22	816856A 1	FUEL CONNECTOR	1		
29	10	40003 32	SCREW (M6 X 35)	1		
30	32	99128 78	HOSE (4-1/4 IN.)	1		
31	54	63300 1	CLAMP	1	(NO STAMPING)	
31	54	63300 3	CLAMP	1	(STAMPED '3')	
32		42859 3	SOLENOID VALVE	1	(USE WITH NO STAMPING CLAMP)	3
33	89	819503A 5	SOLENOID VALVE	1	(USE WITH STAMPED '3' CLAMP)	
34	22	99126 88	HOSE (9-1/2 IN.)	1	(MANUAL BUTTON MOUNTED)	