



5349

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		822344T10	POWER TRIM ASSEMBLY	1		
-	25	827668A	O-RING KIT	1		
2		827670A	SHOCK ROD ASSEMBLY	1		
3		827671A	PILOT CHECK ASSEMBLY	1		
4		827672A	TILT RELIEF VALVE ASSEMBLY	1		
5		827673A	SUCTION SEAT ASSEMBLY	1		
6		827674A	PUMP ASSEMBLY	1		
7		NSS	NOT SOLD SEPARATE	1	(Ball/Spring)	
8		NSS	NOT SOLD SEPARATE	1	(Screw)	
9		NSS	NOT SOLD SEPARATE	1	(Filter)	
10		NSS	NOT SOLD SEPARATE	1	(O Ring)	
11		827675A	MOTOR ASSEMBLY	1		
12		NSS	NOT SOLD SEPARATE	4	(Screw)	
13		NSS	NOT SOLD SEPARATE	4	(Washer)	
14		88238A15	CABLE	1		
15		NSS	NOT SOLD SEPARATE	1	(O Ring)	
16		NSS	NOT SOLD SEPARATE	1	(Coupler)	
17		827676	MEMORY PISTON	1		
18		813442A	MANUAL RELEASE ASSEMBLY	1		
19	19	811613	PLUG ASSEMBLY	1		
20		831276T	BRACKET	1		
21	84	826802A	HARNESS	1		
22	10	821291	SCREW, (M6 x 25)	2		
23		828151A	RELAY ASSEMBLY	2		
24		828102	BRACKET	2		
25	25	818967	GROMMET	2		
26	23	818968	BUSHING	2		
27		NSS	NOT SOLD SEPARATE	2	(Decal)	
28	10	878609	SCREW, (#10-16 x .600)	1		
29		69205	C WASHER	1		
30	54	22740	CLIP	2		