



23445

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		898101T59	BRACKET, Electrical	1	
2	10	823042	BOLT	5	
3	89	853809001	STARTER SOLENOID	1	4
4	89	898103T09	RELAY ASSEMBLY, Solenoid Swit	1	
5	87	898103T10	SWITCH ASSEMBLY, PTT Soleno	1	
6	85	853816004	BOOT, (Red)	4	
7	84	898101175	HARNES, Solenoid Switch (Red)	2	
8	84	853740 8	CABLE, (Black)	2	
9	10	823042 7	BOLT	1	4
10		898101T60	COVER, Electrical Bracket	1	
11	23	95361	BUSHING	2	
12	10	16705 1	BOLT, (M6 x 20)	2	
13		898101T37	HOLDER, Cord	1	
14		898101094	HOLDER	1	
15	10	823042	BOLT	3	
16		898101134	ALARM, Over-Heat (Handle)	1	
17		898101118	SENSOR, MAT	1	
18	25	898101119	GROMMET, Mat Sensor	1	
19	32	898101072	HOSE, To Intake Manifold	1	
20	32	898101073	HOSE, To Intake Silencer	1	
21		898103005	VALVE ASSEMBLY	1	
22	10	16705	BOLT	3	
23	12	895118002	WASHER	6	
24	23	95286 8	COLLAR	3	
25		898101158	MOUNT, Rubber	3	
26		898101136	PLATE	1	
27	12	16826	WASHER	1	
28	11	40021 2	NUT, (M6)	1	
29	10	823042041	BOLT	2	4
-	50	899783A01	START KIT, Electric	1	