



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	177	1600A 2	TOP COWL ASSEMBLY	1,1,1,1		
2	16	20500	STUD, REAR - TOP COWL TO C	2,2,2,2		
3	16	20353	STUD, FRONT-TOP COWL TO C	2,2,2,2		
4	25	20116	GROMMET, CHOKE KNOB	1,1,1,1		
5	37	28988A 1	DECAL SET, TOP COWL (COLOR)	1,1,1,1		
5	37	28989A 1	DECAL SET, TOP COWL (WHITE)	1,1,1,1		
5	37	29834A 1	DECAL SET, TOP COWL (NOT AS)	1,1,1,1		
5	37	31121A 1	DECAL SET, TOP COWL	1,1,1,1		
6	23	20326	SPACER, TOP COWL STUD	2,2,2,2		
7	12	20346	WASHER, TOP COWL STUD (3/4	4,4,4,4		
8	12	20028	WASHER, TOP COWL STUD (1/1	4,4,4,4		
8	12	20583	WASHER, TOP COWL STUD (1/3	4,4,4,4		
9	11	20361	NUT, TOP COWL FASTENING	4,4,4,4		
10		20155	RETAINER, STARTER SPRING	1,1,1,1		
11	24	29340A 1	SPRING, STARTER REWIND	1,1,1,1		
12	23	28912	BUSHING, SPRING GUIDE	1,1,1,1		
13	50	28908	SHEAVE ASSEMBLY	1,1,1,1		
13	50	30994	SHEAVE ASSEMBLY	1		
14		20162	PAWL, STARTER	3,3,3,3		
14		30596	PAWL, STARTER	3		
15	13	29402	WASHER, WAVE-STARTER PAW	3,3,3,3		
15	13	30597	WASHER, WAVE-STARTER PAW	3		
16	23	28919	BUSHING, NYLON-SHEAVE SHAF	1,1,1,1		
17	23	28911	SPACER, SHEAVE SHAFT	1,1,1,1		
18		26179	RETAINER, WAVE WASHER	1,1,1,1		
19	12	26180	WASHER, WAVE WASHER RETA	1,1,1,1		
20	13	20160	WASHER, WAVE-RETAINER TEN	1,1,1,1		
21		20164	PLATE, RETAINER STARTER PA	1,1,1,1		
21		30595	PLATE, RETAINER STARTER PA	1		
22		28913	SHAFT, SHEAVE	1,1,1,1		
23	50	28985A 1	STARTER CABLE ASSEMBLY	1,1,1,1		
24		28747	HANDLE, STARTER CABLE	1,1,1,1		
25		28748	RETAINER, STARTER CABLE AN	1,1,1,1		
26		28944	HANDLE, TOP COWL	1,1,1,1		
27	10	29199	SCREW, HANDLE TO TOP COWL	2,2,2,2		
27	10	28667	SCREW, HANDLE TO TOP COWL	2,2,2,2		
--	13	26992	LOCKWASHER, HANDLE FASTER	2,2,2,2		
28	10	22421	SCREW, HANDLE TO TOP COWL	1,1,1,1		
29	11	20361	NUT, HANDLE FASTENING SCRE	1,1,1,1		
30		28967	SCREEN, VENT-TOP COWL	1,1,1,1		
11		28968	NUT, SPEED VENT SCREEN TO	4,4,4,4		