



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1326	1119	CARBURETOR ASSEMBLY, COMI	2,2,2,2	SERIAL 00000000-01231089	(2)8,(3)1
1	1326	1604	CARBURETOR ASSEMBLY, COMI	2,2,2,2	SERIAL 01231090-01324410	(4)3
1	1334	1701	CARBURETOR ASSEMBLY, COMI	2,2,2,2	SERIAL 01324411-09999999	
2	1399	110A 1	FLOAT ASSEMBLY	2,2,2,2		
3	17	20853	PIN, FLOAT LEVER PINION	4,4,4,4		
4	1399	102	LEVER, FLOAT (LOWER)	2,2,2,2		
5	1399	101	LEVER, FLOAT (UPPER)	2,2,2,2		
6	1399	1138	INLET NEEDLE, SEAT AND GA	2,2,2,2		
7	27	25033	GASKET, INLET SEAT	2,2,2,2		
8	10	20847	SCREW, THROTTLE STOP LEV	2,2,2,2		
9	1399	97	LEVER, THROTTLE STOP (SEE	1,1,1,1		
10	1399	933	SHAFT, THROTTLE	2,2,2,2		
10	1399	1716	SHAFT, THROTTLE	2,2,2,2		
11	24	20869	SPRING, THROTTLE SHAFT RE	1,1,1,1		
11	24	26890	SPRING, THROTTLE SHAFT RE	1,1,1,1		
--	27	20848	GASKET, MAIN ADJUSTMENT S	2,2,2,2		
--	1399	94	GLAND, MAIN ADJUSTMENT SI	2,2,2,2		
--	1399	108	PACKING, MAIN ADJUSTMENT	2,2,2,2		
--	11	20849	NUT, MAIN ADJUSTMENT SCR	2,2,2,2		
--	1399	932	SCREW, MAIN ADJUSTMENT	2,2,2,2		
12	1399	1655	JET, MAIN FUEL (.055)	2,2,2,2		
12	1399	1653	JET, MAIN FUEL (.053)	,OPT,0		
12	1399	1651	JET, MAIN FUEL (.051)	,OPT,0		
12	1399	1649	JET, MAIN FUEL (.049)	,OPT,0		
13	27	28409	GASKET, MAIN FUEL JET	2,2,2,2		
14	24	27160	SPRING, IDLE ADJUSTMENT S	2,2,2,2		
15	1399	931	SCREW, IDLE ADJUSTMENT	2,2,2,2		
15	1399	1623	SCREW, IDLE ADJUSTMENT	2,2,2,2		
15	1399	1713	SCRW, IDLE ADJUSTMENT	2,2,2,2		
16	1399	99	GASKET, FLOAT BOWL COVER	2,2,2,2		
17	1399	1133	COVER, FLOAT BOWL	2,2,2,2		
18	1399	1754	SCREEN, FILTER-NOT AS SHO	2,2,2,2		
19	10	20854	SCREW, FLOAT BOWL COVER	2,2,2,2		
20	10	25850	SCREW, FLOAT BOWL COVER	2,2,2,2		
21	27	25851	GASKET, STRAINER COVER (L	2,2,2,2		
22	27	25849	GASKET, STRAINER COVER (S	2,2,2,2		
23	1399	1135	COVER, STRAINER	2,2,2,2		
24	27	25848	GASKET, STRAINER COVER SC	2,2,2,2		
25	10	25822	SCREW, STRAINER COVER FA	2,2,2,2		
26	1399	1715	NOZZLE, MAIN	2,2,2,2		
27	10	22178	SCREW, PLUG MAIN NOZZLE	2,2,2,2		