



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	808	1321A 4	CYLINDER BLOCK AND CRANKC	1,1,1,1		
-		N. S. S.	CRANKCASE	1,1,1,1		
-	17	20323	DOWEL PIN, CYLINDER BLOCK	1,1,1,1		
-	17	20032	DOWEL PIN, CYLINDER BLOCK	1,1,1,1		
2	23	26348	BUSHING, CRANKCASE	2,2,2,2		
3	16	25885	STUD, CARBURETOR MOUNTI	4,4,4,4		
4	17	20033	DOWEL PIN, CRANKCASE TO C	2,2,2,2		
5	16	29988	STUD, CRANKCASE TO DRIVE	2,2,2,2		
6	16	29990	STUD, CYLINDER BLOCK TO D	2,2,2,2		
7	16	29989	STUD, SYLINDER BLOCK TO D	4,4,4,4		
8	22	30139	PLUG, PIPE - WATER PRESSUR	1,1,1,1		
9	10	22039	SCREW, CRANKCASE TO CYLIN	4,4,4,4		
10	10	22040	SCREW, CRANKCASE TO CYLIN	14,14,1		
--	12	20084	WASHER; CRANKCASE SCREW	2,2,.....		
11	11	29250	NUT, CRANKCASE FASTENING S	18,18,1		
12	10	20089	SCREW, MAIN BEARING LOCKIN	2,2,2,2	SERIAL 00000000-01352947	
12	10	26801	SCREW, MAIN BEARING LOCKIN	2,2,2,2	SERIAL 01352948-09999999	
13	14	20091	TAB WASHER, BEARING LOCKIN	3,3,3,3		
14	10	20359	SCREW, CENTER MAIN BEARING	1,1,1,1		
15	00	339A 1	END CAP ASSEMBLY, UPPER	1,1,1,1		
16	30	20080	BEARING, BALL - UPPER END C	1,1,1,1		
17	25	20081	"O" RING, UPPER END CAP	1,1,1,1		4
18	26	29476	OIL SEAL	1,1,1,1		
19	15	20082A 1	SHIM, UPPER END CAP TO CRA	AR,AR,		
--	13	26993	LOCKWASHER, UPPER END CAF	4,4,.....		
20	10	23703	SCREW, UPPER END CAP MOUN	4,4,.....		
20	10	29198	SCREW, UPPER END CAP MOUN	4,4,4,4		
21	1102	1484A 1	END CAP ASSEMBLY, LOWER	1,1,1,1		
22	30	20080	BEARING, BALL - LOWER END	1,1,1,1		
23	25	20081	"O" RING, LOWER END CAP	1,1,1,1		4
24	26	29476	OIL SEAL, UPPER	1,1,1,1		
24	26	29477	OIL SEAL, LOWER	1,1,1,1		
--	21	28481A 1	CHECK VALVE ASSEMBLY, LOV	1,1,1,1		
25	15	20085A 1	SHIM, LOWER END CAP TO CRA	AR,AR,		
--	13	26993	LOCKWASHR, LOWER END CAP	3,3,.....		
26	10	23703	SCREW< LOWER END CAP MOU	3,3,.....		
26	10	29198	SCREW, LOWER END CAP MOUT	3,3,3,3		
27	27	26923	GASKET, CYLINDER BLOCK TO	1,1,1,1		4
28		26922	PLATE, EXHAUST MANIFOLD	1,1,1,1		
27	27	26923	GASKET, MANIFOLD PLATE TO C	1,1,1,1		4
29		28240	COVER, EXHAUST MANIFOLD	1,1,1,1		