



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	22339	NUT, FLYWHEEL	1,1,1,1		
2	12	26617	WASHER, FLYWHEEL NUT	1,1,1,1		
3	28	20994	KEY, FLYWHEEL	1,1,1,1		
4	208	1535A 1	FLYWHEEL ASSEMBLY (LUG HEI	1,1,1,1		
4	208	1385A 1	FLYWHEEL ASSEMBLY (LUG HEI	1,1,1,1		
4	211	1414A 4	FLYWHEEL ASSEMBLY (WITH SF	1,1,1,1		(2)3
4	211	1414A 2	FLYWHEEL ASSEMBLY (WITHOL	1,1,1,1		(2)3
4	211	1414A 7	FLYWHEEL ASSEMBLY (WITHOL	1,1,1,1		(2)5
5		22823	PULLEY, FLYWHEEL SEE NOT	1,1,1,1		
6	12	25293	WASHER, PULLEY TO FLYWHE	1,1,1,1		
-		29788	FLANGE, FLYWHEEL PULLEY	1,1,1,1		
-		30306	PULLEY, FLYWHEEL SEE NOTE	1,1,1,1		
-		29787	HUB, FLANGE-FLYWHEEL PULI	1,1,1,1		
7	17	26618	DOWEL PIN, FLYWHEEL PULLE	1,1,1,1		
-	12	28927	WASHER, RATCHET TO FLYWI	3,3,3,3		
8	50	25263	RATCHET, FLYWHEEL	1,1,1,1		
9	10	29238	CSREW, RATCHET TO FLYWHE	3,3,3,3		
10	398	1455	STATOR, ALTERNATOR-FLYWHE	1,1,1,1		
11		22647	DISCONNECT, KNIFE SPLICE-S	2,2,2,2		
12	32	26528	SLEEVE, RUBBER-STATOR LEAC	2,2,2,2		
13	10	29249	SCREW, STATOR TO UPPER EN	4,4,4,4		
14	54	24836	CLIP, STATOR LEAD TO CRANKC	1,1,1,1		
15	10	25255	SCREW, STATOR LEAD CLIP FAC	1,1,1,1		
15	10	30009	SCREW, STATOR LEAD CLIP FAC	1,1,1,1		