



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		23009A 1	FUEL PUMP ASSEMBLY	1,1,.....		
1		29178A 2	FUEL PUMP ASSEMBLY	1,1,1,1		
1		30269A 2	FUEL PUMP ASSEMBLY	.....1		
2	27	23005	GASKET, CHECK VALVE TO HO	2,2,2,2		4
3	21	30430	VALVE, CHECK	2,2,2,2		
4		23004	RETAINER, CHECK VALVE	1,1,1,1		
5	10	20037	SCREW, RETAINER TO HOUSII	2,2,2,2		
6	27	24863	GASKET, FUEL PUMP	2,2,2,2		4
7		23014	DIAPHRAGM, FUEL PUMP	1,1,1,1		4
	22	29380	PLUG, PIPE - FUEL PUMP	1,1,1,1		
8		23008	COVER, FUEL PUMP	1,1,1,1		
9	27	30276	GASKET, FUEL PUMP COVER	1,1,1,1		4
10	10	29030	SCREW, FUEL PUMP MOUNTIN	2,2,.....	SERIAL 00000000-01261034	(1)3,(2)3
10	10	29126	SCREW, FUEL PUMP MOUNTING	2,2,2,2	SERIAL 01261035-09999999	(1)8,(2)8
11	10	29029	SCREW, FUEL PUMP MOUNTING	1,1,1,1		
--	22	23595	CONNECTOR, PUMP OUTLET TC	1,1,.....	SERIAL 00000000-01261034	(1)3,(2)3
--	22	24690	ELBOW, PUMP OUTLET TO FUEL	1,1,.....	SERIAL 00000000-01261034	(1)3,(2)3
12	22	22993	CONNECTOR, FUEL LINE TO FUE	..1,1,1;		
13	22	22946	SLEEVE, RUBBER	..1,1,1;		
14	11	22948	NUT, ELBOW	..1,1,1;		
15	32	30035	FUEL LINE, FUEL PUMP TO LOW	1,1,1,1		
--	22	22995	ELBOW, FUEL PUMP INLET	1,1,.....		
16	22	22995	ELBOW, FUEL PUMP OUTLET TC	..1,1,1;		
17	22	22946	SLEEVE, RUBBER	1,1,1,1		
18	11	22948	NUT, ELBOW	1,1,1,1		
19	32	23761	FUEL LINE, FUEL PUMP TO ADAF	1,1,.....		
19	32	30036	FUEL LINE, FUEL PUMP TO ADAF	..1,1,1;		
20		22833	ADAPTOR, CHECK UNIT (FUEL LI	1,1,1,1		
21		23069	STEM, CHECK UNIT ADAPTOR	1,1,1,1		
22	25	20415	"O" RING, ADAPTOR STEM	1,1,1,1		
23	24	23067	SPRING, ADAPTOR STEM	1,1,1,1		
24		23068	CUP WASHER, ADAPTOR	1,1,1,1		
25	10	20784	SCREW, ADAPTOR TO BOTTOM	2,2,2,2		
26	11	24652	NUT, ADAPTOR SCREW	2,2,2,2		
--	22	25443	ELBOW, UPPER FILTER TO FUEL	1,1,.....	SERIAL 00000000-01261034	(1)3,(2)3
--	22	22949	ELBOW, UPPER FILTER TO FUEL	1,1,.....	SERIAL 01261035-09999999	(1)8,(2)8
27	32	25228	FUEL LINE, UPPER TO LOWER F	1,1,.....	SERIAL 00000000-01261034	(1)3,(2)3
27	32	30038	FUEL LINE, UPPER TO LOWER F	1,1,1,1	SERIAL 01261035-09999999	(1)8,(2)8
27	32	30040	FUEL LINE, UPPER TO LOWER F	..1,1,1;		
28	22	23763	TEE ASSEMBLY, LOWER FILTER	1,1,.....	SERIAL 00000000-01261034	(1)3,(2)3
28	22	26955	TEE ASSEMBLY, LOWER FILTER	1,1,1,1	SERIAL 01261035-09999999	(1)8,(2)8