



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
32		25138	CAM, LOWER REVERSE LOCKI	1,1,1,1		
33		25139	CAM, UPPER REVERSE LOCKIN	1,1,1,1		
33		29823	CAM UPPER REVERSE LOCKIN	1,1,1,1		
34	12	20260	WASHER, GREASE FILLER ANI	2,2,2,2		
35	10	28634	SCREW, GREASE FILLER AND	2,2,2,2		
36	12	20262	WASHER, GEAR HOUSING VEN	1,1,1,1		
37	10	28653	SCREW, GEAR HOUSING VENI	1,1,1,1		
38		36288	CAM, SHIFT	1,1,1,1		
38		30147	CAM, SHIFT	1,1,1,1		
39		20930	FOLLOWER, CAM	1,1,1,1		
40		20843	SLIDE, CROSS PIN	1,1,1,1		
41	24	20254	SPRIDE, CAM FOLLOWER PIN	1,1,1,1		
42	15	20928A 1	SHIM, BALL BEARING TO GEAR	AR,AR		
43	30	20840	BEARING, BALL - FORWARD	1,1,1,1		
44	43	20975	FORWARD GEAR ASSEMBLY	1,1,1,1		
45	31	20249	BEARING, ROLLER - FORWARD	1,1,1,1		
46	52	32189	RATCHET, SLIDING CLUTCH	1,1,1,1		
47	17	20841	PIN, CROSS - RATCHET TO PR	1,1,1,1		
48	53	20842	RING, RETAINING - CROSS PIN	1,1,1,1		
49	44	25254	SHAFT, PROPELLER	1,1,1,1		
50	43	20975	REVERSE GEAR ASSEMBLY	1,1,1,1		
51		20864	RING, ADAPTOR - BALL BEAR	1,1,1,1		
52	30	20839	BEARING, BALL - REVERSE C	1,1,1,1		
53	15	20927A 1	SHIM, ADAPTOR RING TO GEAR	AR,AR		
54	25	20863	"O" RING, BEARING CARRIER	1,1,1,1		4
55		20862A 1	BEARING CARRIER ASSEMBLY	1,1,1,1		
56	31	20249	BEARING, ROLLER	1,1,1,1		
57	26	23300	OIL SEAL	1,1,1,1		
58	12	22970	WASHER, GEAR HOUSING COV	1,1,1,1		
59		20865	COVER, GEAR HOUSING	1,1,1,1		
60	12	25251	WASHER, BACKING (1/8")	AR,AR		
--	48	29296A 2	PROPELLER ASSEMBLY (2 BLAD	1,1,1,1		
61	12	25252	WASHER, BACING (1/32")	1,1,1,1		
62	14	25250	TAB WASHER, PROPELLER NUT	1,1,1,1		
63	11	20837	NUT, PROPELLER (ALUMINUM)	1,1,1,1		
63	11	29825	NUT, PROPELLER (NYLON)	OPT,01		