


NOTE #1
 The enclosed parts must be ordered if the starter sheave (ref. #22) is notched on both sides.



NOTE #2
 The enclosed parts must be ordered if the starter sheave (ref. #22) is notched on the top side only.



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	20166	NUT, SHEAVE SHAFT (LEFT HAN	1		1
2	14	61004	TAB WASHER, SHREAVE SHAFT	1		1
3	25	39597	GROMMET, STARTER HOUSING	2		1
4		76141	CABLE ASSEMBLY	1	INTERLOCK-MANUAL	
5	10	32228	SCREW	1	CABLE TO EXHAUST PLATE (5/16	
6	10	69022	SCREW	1	CABLE TO STARTER HOUSING	
7		42820	CAM	1	INTERLOCK -MANUAL	1
8	10	76138	SCREW	1	INTERLOCK CAM ATTACHING (1	1
9	24	76140	SPRING	1	INTERLOCK CAM SCREW -MANI	1
10		79371	ACTUATOR	1	INTERLOCK -MANUAL	1
11	10	76137	SCREW	1	INTERLOCK ACTUATOR ATTAC	1
12	24	76139	SPRING	1	INTERLOCK ACTUATOR SCREW	1
13	12	30191	WASHER	1	INTERLOCK CABLE -MANUAL	
14	18	27769	COTTER PIN	1	INTERLOCK CABLE TO ACTUAT	
15		55860	PULLEY, STARTER	1		1
16	10	45210	SCREW, PULLEY TO STARTER F	1		1
17	12	22887	WASHER, PULLEY SCREW	3		1
18	23	30977	SPACER, PULLEY SCREW	1		1
19		94121	RETAINER, STARTER ROPE	1		1
20	11	24656	NUT, PULLEY SCREW	1		1
21		76080A	STARTER HOUSING	1	SEE NOTE #1 ON ILLUSTRATIO	
22	50	94338A	STARTER SHEAVE	1	SEE NOTE #1 ON ILLUSTRATIO	
23		91936	STARTER PAWL	1	SEE NOTE #1 ON ILLUSTRATIO	
21		76079	STARTER HOUSING	1	SEE NOTE #2 ON ILLUSTRATIO	1
22	50	44255A	STARTER SHEAVE	1	SEE NOTE #2 ON ILLUSTRATIO	1
23		44508	STARTER PAWL	1	SEE NOTE #2 ON ILLUSTRATIO	1
24	10	88759	SCREW, STARTER HOUSING TO	2		
24	10	88760	SCREW, STARTER HOUSING TO	1		
25	13	26993	LOCKWASHER, STARTER HOUS	3		
26		61002	PLATE, STARTER REWIND	1		1
27	24	39502A	SPRING, STARTER REWIND	1		1
28	23	87649	BUSHING, SPRING GUIDE	1		1
29	24	87651	SPRING, STARTER PAWL	1		
30	53	87706	"E" RING, STARTER PAWL	1		1
31	23	63061	SPACER, SHEAVE SHAFT	1		1
33		94962	LEVER	1		1
34	13	20160	WAVE WASHER	1		1
35		87656	SHEAVE SHAFT	1		1
36	50	28985A	STARTER ROPE ASSEMBLY	1		1
36		47341A	STARTER ROPE ASSEMBLY	1	(FOR MANUAL STARTING)	
37		79470A	RETAINER ASSEMBLY, STARTER	1		