



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	1427	5611A 5	CLAMP BRACKET ASSEMBLY (M...	2		
1	1427	5611A 4	CLAMP BRACKET ASSEMBLY (EL...	2		
2	10	90470A 3	THUMB SCREW ASSEMBLY (M...	2		
2	10	78492A 1	THUMB SCREW ASSEMBLY (EL...	2		
3	10	78495 1	SCREW, WASHER TO THUMB...	2		
4	12	78493	WASHER, THUMB SCREW	2		
5		75043	CAP, THUMB SCREW (ELECT...	2		
6	17	49930A 1	TILT LOCK PIN ASSEMBLY	1		
7	23	59623	SPACER, CLAMP BRACKET STU...	1		
8	16	59625	STUD, CLAMP BRACKET	1		
9	13	26393	LOCKWASHER, STUD	2		
10	11	28770	NUT, STUD	2		
11		74528	TILT TUBE	1		
12	12	52864	WASHER, CLAMP BRACKET TO...	6		
13	11	56041	NUT, TILT TUBE	2		
15	10	68298	BOLT	2	CLAMP BRACKET TO BOAT TR...	
16	12	68410	WASHER, CLAMP BRACKET BOL...	2		
17	11	99405	NUT, CLAMP BRACKET BOLT	2		
18		88798A 1	PIN ASSY, (SHORT SHAFT) MAN...	1		
18		88798A 2	PIN ASSY, (LONG SHAFT) MANU...	1		
18		69540A 3	PIN ASSY (SHORT SHAFT)	1	ELECTRIC (EARLY MODELS)	
18		69540A 4	PIN ASSY (LONG SHAFT) (EARL...	1		
19		30711	BUMPER, STEERING ARM	1		
20	10	66897	SCREW, UPPER MOUNT TO STE...	2		
21		62297	BUMPER, STEERING ARM W/O...	1		
22		76535	BRACKET, RIDE-GUIDE ATTACH...	1		
23	10	34352	SCREW, BRACKET TO STEERING...	2	W/O TILLER HANDLE	
24		76533	STRAP, BRACKET SCREW W/O...	1		
25	12	52865	WASHER, SWIVEL PIN	1		
26	1481	7656A 1	SWIVEL BRACKET ASSEMBLY (S...	1		
26	1480	7655A 1	SWIVEL BRACKET ASSEMBLY (L...	1		
27	26	32911	OIL SEAL, SWIVEL BRACKET	2		
28	22	74036	GREASE FITTING - SWIVEL BR...	3		
29		47913A 2	LEVER ASSEMBLY, TILT LOCK - F...	1		
30	10	69087	SCREW	2	TILT LOCK AND STOP LEVER TI...	
31	11	29250	NUT, TILT LOCK AND STOP LEV...	2		
32		47912A 2	LEVER ASSEMBLY, TILT STOP - F...	1		
33	23	47911	BUSHING, TILT LOCK AND STOP...	2		
34	13	34632	WASHER, WAVE - TILT LOCK AN...	2		
35	12	56720	WASHER, TILT LOCK AND STOP...	2		
36	11	29250	NUT	2	TILT LOCK AND STOP LEVER TI...	