


### TRANSOM BRACKET



### TRANSOM BRACKET

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	3508	9751A 1	TRANSOM BRACKET ( PORT )	1	
2	22	98727	GREASE FITTING	1	
3	17	99604	GROOVE PIN	1	
4	3507	9750T	TRANSOM BRACKET ( STARBOA	1	
5		19618A 2	TILT LOCK LEVER	1	
6	24	99622	SPRING	1	
7	23	65830	NYLINER	1	
8	24	812708	SPRING	1	
9		812709T	KNOB	1	
10	17	99615	GROOVE PIN	1	
11	12	19619	WASHER	2	
12		18486T	ANCHOR BRACKET	1	
13		43396A 2	ANODE ASSEMBLY	1	
14	10	40003 32	SCREW	2	
15	12	29245	WASHER	2	
16	10	40003 54	SCREW ( 30 MM )	5	
16	10	40003 55	SCREW ( 35 MM )	1	
17	13	40025 7	LOCKWASHER	4	
18	11	40063 5	NUT	2	
19		19613A 1	TILT PIN ASSEMBLY	1	
20		19614	TILT TUBE	1	
21	11	56041	NUT	2	
22		19624A 1	SEAL KIT	1	
23	54	22740	CLIP POWER TRIM	1	
24		69205	"C" WASHER POWER TRIM	1	
25	10	812832	SCREW POWER TRIM	1	
26	10	814259	SCREW	4	
27	12	28421	WASHER	4	
28	11	35000	NUT	4	
29		19385 21	LINK NON-POWER TRIM	1	
30		19615A 4	TILT LEVER NON-POWER TRIM	1	
31	23	812707	BUSHING NON-POWER TRIM	1	
32	12	815796	WASHER ( .030" ) NON-POWER	1	
32	12	19605	WASHER ( .060" ) NON-POWER	1	
33	13	99611	WAVE WAHER NON-POWER TR	1	
34		19621	TILT KNOB NON-POWER TRIM	1	
35	10	19611	SCREW NON-POWER TRIM	1	
36	10	76841	SCREW ( 3-1/2" ) NON-POWER	2	
37		812432T	MOUNTING BRACKET ( STARBO,	1	NON-POWER TRIM
37		812433T	MOUNTING BRACKET ( PORT )	1	NON-POWER TRIM
38	10	88422	SCREW ( 4" ) NON-POWER TRIM	4	