



Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|----------|-----------------------------|-----|---------------------------|----------|
| 1 | 2139 | 7642A 2 | BOTTOM COWL ASSEMBLY | 1 | | |
| 2 | | 57786 | COVER, PLUG MANUAL | 1 | | |
| 3 | 10 | 61802 | SCREW (7/8") MANUAL | 2 | | |
| 4 | | 88618 | PLUG, BOTTOM COWL MANU | 1 | | |
| 5 | 10 | 48409 | SCREW MANUAL | 1 | | |
| 6 | 12 | 56681 | WASHER MANUAL | 1 | | |
| 7 | 27 | 62860 1 | GASKET | 1 | | 3 |
| 8 | | 39622 | SEAL, RUBBER - EXHAUST PLAT | 1 | | |
| 9 | | 42818A 1 | PLATE ASSEMBLY, EXHAUST EX | 1 | | |
| 10 | 23 | 27132 | BUSHING, FLANG EXHAUST PL | 1 | | |
| 11 | 12 | 38453 | WASHER, NYLON - WATER OUL | 1 | | |
| 12 | 26 | 38452 | SEAL, RUBBER - WATER OUT | 1 | | 3 |
| 13 | | 79799 | HOUSING, WATER INLET TUBE | 1 | | |
| 14 | 27 | 79797 1 | GASKET, HOUSING | 1 | | 3 |
| 15 | 10 | 79798 | SCREW, HOUSING TO EXHAUS | 2 | | |
| 16 | 27 | 38501 1 | GASKET | 1 | EXHAUST PLATE TO DRIVE SH | 3 |
| 18 | | 39616 | BOOT, CONTROL CABLE - BOTTC | 1 | | |
| 19 | | 39555 | COVER PLATE | 1 | | |
| 20 | 10 | 69014 | SCREW, COVER PLATE TO BOT | 3 | | |
| 21 | | 76176 | LEVER, FRONT COVER | 1 | | |
| 22 | 24 | 76177 | SPRING, FRONT COVER LEVER | 1 | | |
| 23 | 17 | 26541 | ROLL PIN, LEVER TO BOTTOM C | 1 | | |
| 24 | | 47969 | KNOB AND SHAFT, CHOKE | 1 | | |
| 25 | 12 | 30314 | WASHER, CHOKE SHAFT | 1 | | |
| 26 | 24 | 47968 | SPRING, COMPRESSION - CHOKI | 1 | | |
| 27 | | 55180 | LEVER, CHOKE | 1 | | |
| 28 | 87 | 69508A32 | STOP SWITCH ASSEMBLY | 1 | MANUAL PUSH BUTTON SWITC | |
| 29 | 87 | 99525A 1 | COVER, STOP SWITCH | 1 | MANUAL PUSH BUTTON SWITC | |
| 30 | 111 | 69844 | NUT, STOP SWITCH | 1 | MANUAL PUSH BUTTON SWITC | |
| 31 | | 88238A 4 | GROUND STRAP, BOTTOM COW | 2 | | |
| 32 | 10 | 69014 | SCREW, GROUND STRAP (1/2") | 2 | | |
| 33 | | 76132 | BRACKET, SUPPORT - TOP COW | 1 | | |
| 34 | | 60577 | MOUNT, RUBBER - REAR SUPPC | 2 | | |
| 35 | 12 | 35044 | WASHER, RUBBER MOUNT | 2 | | |
| 36 | 13 | 26992 | LOCKWASHER, RUBBER MOUNT | 2 | | |
| 37 | 11 | 36069 | NUT, RUBBER MOUNT | 2 | | |
| 38 | | 90435 | MOUNT, RUBBER - REAR SUPPO | 1 | | |
| 39 | 11 | 20184 | NUT, RUBBER MOUNT | 2 | | |
| 40 | 10 | 37562 | SCREW, REAR SUPPORT BRACK | 4 | | |
| 41 | 13 | 26993 | LOCKWASHER | 4 | | |
| 42 | | 95967T | BRACKET SUPPORT, TOP COWL | 1 | | |