



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	1427	5611A 5	CLAMP BRACKET ASSEMBLY (M/	2		
1	1427	5611A 4	CLAMP BRACKET ASSEMBLY (EL	2		
2	10	90470A 3	THUMB SSCREW ASSEMBLY (I	2		
2	10	78492A 1	THUMB SCREW ASSEMBLY (E)	2		
3	10	78495 1	SCREW, WASHER TO THUMB	2		
4	12	78493	WASHER, THUMB SCREW	2		
5		75043	CAP THUMB SCREW (ELECT)	2		
6	17	49930A 1	TILT LOCK PIN ASSEMBLY	1		
7	23	59623	SPACER, CLAMP BRACKET STU	1		
8	16	59625	STUD, CLAMP BRACKET	1		
9	13	26393	LOCKWASHER	2		
10	11	28770	NUT	2		
11		74528	TILT TUBE	1		
12	12	52864	WASHER	6		
13	11	56041	NUT, TILT TUBE	2		
15	10	68298	BOLT (LOWER)	2		
16	12	68410	WASHER (LOWER)	2		
17	11	99405	NUT	2		
18		88798A19	STEERING ARM (SHORT SHAFT)	1		
18		88798A20	STEERING ARM (LONG SHAFT)	1		
19		30711	BUMPER	1		
20	10	66897	SCREW	2		
21		62297	BUMPER	1		
22		76535	BRACKET W/O TILLER HANDLE	1		
23	10	34352	SCREW (7/8") W/O TILLER HAN	2		
24		76533	STRAP W/O TILLER HANDLER	1		
25	12	52865	WASHER	1		
26	1481	7656A 1	SWIVEL BRACKET (SHORT SHAF	1		
26	1480	7655A 1	SWIVEL BRACKET (LONG SHAF	1		
27	26	32911	OIL SEAL	2		
28	22	74036	GREASEFITTING	3		
29		47913A 2	LEVER ASSEMBLY (PORT)	1		
30	10	69087	SCREW	2		
31	11	29250	NUT	2		
32		47912A 2	LEVER ASSEMBLY (STARBOARD)	1		
33	23	47911	BUSHING	2		
34	13	3462	WAVE WASHER	2		
35	12	56720	WASHER	2		
36	11	29250	NUT	2		
37	17	25598	ROLL PIN	1		
38		56249	SHAFT	1		