


Parts List



Ref	Class	Part	Description	Qty	Comment	Footnote
1		14360A16	FUEL PUMP ASSEMBLY	1		
2	21	42990A	DIAPHRAGM KIT	1		
3			CHECK VALVE, RUBBER	2		9
4			GASKET, BOOST	1		9
5			DIAPHRAGM	2		9
6			GASKET, PULSE	1		9
7			SPRING	1		9
8			CAP	1		9
9			DISC, RUBBER	2		9
10			RETAINER	2		9
11			SPRING	1		9
12			CAP	1		9
13		98775A	2 PLATE, FUEL PUMP	1		
14	22	56800	PIPE PLUG	1		
15	22	19688	FITTING	1		
16	10	16562	SCREW, FUEL PUMP (10-24)	3		
16	10	40057132	SCREW, FUEL PUMP (6 MM)	3		
17	32	99129	76 TUBING	2		
18	35	816296	1 FUEL FILTER	1		
19	54	816311	STA-STRAP, FUEL TUBING	AR		
20	54	55098	CLIP	1		
21	10	41508	SCREW, DIP	1		
22	32	99127109	TUBING	2		
23	22	19688	ELBOW, FUEL LINE	1		
24	22	15781A10	FUEL CONNECTOR METAL	1		
25	25	14579	GROMMET, FUEL CONNECTOR	1		
24	22	816856A	3 FUEL CONNECTOR PLASTIC	1		
25	25	15102	GROMMET, FUEL CONNECTOR	1		
26	10	20784	SCREW, FUEL CONNECTOR	1		
27	12	71055	WASHER, FUEL CONNECTOR SC	1		
28	11	36069	NUT, FUEL CONNECTOR SCREW	1		