



FUEL PUMP ASSEMBLY

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		30269A 2	FUEL PUMP ASSEMBLY	1,1		
2	27	23005	GASKET, CHECK VALVE TO HO	2,2		
3	21	30430	VALVE, CHECK	2,2		
4		23004	RETAINER, CHECK VALVE	1,1		
5	10	20037	SCREW, RETAINER TO HOUSII	2,2		
6	27	24863	GASKET, FUEL PUMP	2,2		
7		23014	DIAPHRAGM, FUEL PUMP	1,1		
8		30275	COVER, FUEL PUMP	1,1		
9	27	30276	GASKET, FUEL PUMP COVER	1,1		
10	10	30274	SCREW, FUEL PUMP MOUNTING	2,2		
11	10	29878	SCREW, FUEL PUMP MOUNTIN (1,1		
12	22	22949	CONNECTOR, PUMP INLET TO F	1,1		
13	22	22946	SLEEVE, RUBBER - CONNECTOF	1,1		
14	11	22948	NUT, CONNECTOR TO FUEL LINI	1,1		
15	32	34066	FUEL LINE, FUEL PUMP TO ADAF	1,1		
16		22833	ADAPTOR, CHECK UNIT (FUEL P	1,1		
17		23069	STEM, CHECK UNIT ADAPTOR	1,1		
18	25	20415	"O" RING, ADAPTOR STEM	1,1		
19	24	23067	SPRING, ADAPTOR STEM	1,1		
20		30188	CUP WASHER, ADAPTOR	1,1		
21	10	22421	SCREW, ADAPTOR TO BOTTOM	2,2		
22	11	24652	NUT, ADAPTOR SCREW	2,2		
23	32	30038	FUEL LINE, FUEL PUMP TO CARB	1,		*
23	32	34243	FUEL LINE, FUEL PUMP TO CARB	1,1		
24	22	29085	ELBOW, FUEL PUMP TO CARBU	1,		*